

Installation & Operation Manual Vertical Air Conditioners

CFH3240A/3300A/3360A





Manufactured By:

Industrial Climate Engineering™, An AirX Climate Solutions Brand P.O. Box 5104 • Cordele, Georgia 31010

P.O. Box 5104 • Cordele, Georgia 31010 2002 Hoover St. • Cordele, Georgia 31015 (229) 273-9558 • Fax (229) 273-5154

E-mail: icesales@airxcs.com • Internet: www.acice.com

The most current version of this manual can be found at www.acice.com.

How To Use This Manual

This manual is intended to be a guide to Industrial Climate Engineering's line of vertical air conditioners. It contains installation, troubleshooting, maintenance, warranty, and application information. The information contained in this manual is to be used by the installer as a guide only. This manual does not supersede or circumvent any applicable national or local codes.

If you are installing the air conditioner first read Chapter 1 and scan the entire manual before beginning the installation as described in Chapter 2. Chapter 1 contains general, descriptive information and provides an overview which can speed up the installation process and simplify troubleshooting.

If a malfunction occurs, follow this troubleshooting sequence:

- 1. Make sure you understand how the air conditioner works (Chapters 1 & 3).
- 2. Identify and correct installation errors (Chapter 2).
- 3. Refer to the troubleshooting information in Chapter 4.

If you are still unable to correct the problem, contact the Factory at 1-229-273-9558 for additional assistance.

Please read the following "Important Safety Precautions" before beginning any work.

Important Safety Precautions

- 1. USE CARE when LIFTING or TRANSPORTING equipment.
- 2. TRANSPORT the UNIT UPRIGHT. Laying it down on its side may cause oil to leave the compressor and breakage or damage to other components.
- 3. TURN ELECTRICAL POWER OFF AT THE breaker or fuse box BEFORE installing or working on the equipment. LINE VOLTAGES ARE HAZARDOUS or LETHAL.
- 4. OBSERVE and COMPLY with ALL applicable PLUMBING, ELECTRICAL, and BUILDING CODES and ordinances.
- 5. SERVICE may be performed ONLY by QUALIFIED and EXPERIENCED PERSONS.
 - * Wear safety goggles when servicing the refrigeration circuit
 - * Beware of hot surfaces on refrigerant circuit components
 - * Beware of sharp edges on sheet metal components
 - * Use care when recovering or adding refrigerant
- 6. The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations
- 7. Use COMMON SENSE BE SAFETY-CONSCIOUS

This is the safety alert symbol . When you see this symbol on the air conditioning unit and in the instruction manuals be alert to the potential for personal injury. Understand the signal word DANGER, WARNING and CAUTION. These words are used to identify levels of the seriousness of the hazard.



Failure to comply will result in death or severe personal injury and/or property damage.



Failure to comply could result in death or severe personal injury and/or property damage.



Failure to comply could result in minor personal injury and/or property damage.

IMPORTANT

Used to point out helpful info that will result in improved installation, reliability or operation.

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE.

© 10/2024 Industrial Climate Engineering™, An AirX Climate Solutions Brand

↑ WARNING

- If the information in these instructions are not followed exactly, a fire may result causing property damage, personal injury or loss of life.
- Read all instructions carefully prior to beginning the installation. Do not begin installation if you do not understand any of the instructions.
- Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life.
- Installation and service must be performed by a qualified installer or service agency in accordance with these instructions and in compliance with all codes and requirements of authorities having jurisdiction.

INSTALLER: Affix the instructions on the inside of the building adjacent to the thermostat.

END USER: Retain these instructions for future reference.

MARNING

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

↑ WARNING

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater.

DO NOT pierce or burn.

Be aware that refrigerants may not contain an odor.

Table of Contents

General Description Model Identification	
Model Identification	
Model Identification	
Serial Number Date Code	
Air Flow, Weights and Filter Sizes	
General Operation	8
Programmable Logic Controller	
Optional Controls and Packages	10
Electrical Operation	11
Leak Detection System	11
pter 2 Installation	
Equipment Inspection	14
Installation Requirements	12
Installation Materials	16
Porting and Duct Work	17
Top Flange Installation	18
Installing the Lifting Brackets	18
Mounting the Unit	19
Compressor Chocks Removal	19
Unit Support Recommendations	20
0 Electrical Connections	21
pter 3 Start-Up	
Check-Out of Cooling Cycle	22
Check-Out of Heating Cycle	24
nter 4 Troubleshooting	
•	25
v 1	
1	
<u>-</u>	2.8
Pre-Checks	
nter 6 Service and Charging/Recovery	
	31
Refrigerant Recovery	
	34
<u> </u>	
<u>e</u>	
	Serial Number Date Code Air Flow, Weights and Filter Sizes General Operation Programmable Logic Controller Optional Controls and Packages Electrical Operation Leak Detection System Diter 2 Installation Equipment Inspection Installation Requirements Installation Materials Porting and Duct Work Top Flange Installation Installing the Lifting Brackets Mounting the Unit Compressor Chocks Removal Unit Support Recommendations Delectrical Connections Delectrical Connections Defect 3 Start-Up Check-Out of Cooling Cycle Check-Out of Heating Cycle Check-Out of Heating Cycle Check-Out of Board Diagnosis Deter 5 Maintenance & Repair Scheduled Maintenance Repair Pre-Checks Deter 6 Service and Charging/Recovery Service Leak Detection Charging Procedures

Chapter 8 Warranty 8.1 Limited Product Warranty	36
Chapter 9 Start-Up Check List	
9.1 Start-Up Check List	37
Illustrations	
Figure 1. Programmable Logic Controller	Q
Figure 2a. Typical Electrical Schematic - CFH3240A	
Figure 2b. Typical Electrical Schematic - CFH3300A & CFH3360A	
Figure 3. Top Flange and Lifting Bracket Installation	
Figure 4. Wall Mounting Detail	
Figure 5. Compressor Chock Removal	
Figure 6a. Unit Compression Support Examples.	
Figure 6b. Unit Tension Support Examples	
Figure 7a. Humidistat Wiring to a Marvair Air Conditioner with Reheat	
Tables	
Table 1 Cooling Performance and Air Flow	8
Table 2 Filter Sizes/Part Numbers	8
Table 3 Shipping Weights & Dimensions	
Table 4 Room Size Limitations	
Table 5 Altitude Correction Factor	
Table 6 Minimum Clearances	
Table 7 Voltage Limitations Table 8 Refrigerant Charge	
	52
Appendices	
Appendix A: PLC SetUp and Operation	41
Appendix B: PLC Sequence of Operation	50
Appendix C: PLC Modbus Variables	54
Appendix D: PLC Bacnet Analog Variables	57
Appendix E: PLC Bacnet Binary Variables	59
Appendix F: Fresh Air Damper Installation	60
Appendix G: CFH3240A Center Supply/Top Return w/Economizer Exhaust Hood Installation	62
Appendix H: Optional Condenser Filter Installation	63
Appendix I: DPC200 Differential Pressure Controller.	64

Chapter 1 Description & Specifications

1.1 General Description

Industrial Climate Engineering's (ICE) "CFH" Environmental Control Units are a series of vertical wall-mounted air conditioning systems that provide heating, cooling, and ventilation for electronic equipment shelters, process control centers, E-Houses, and other applications with high internal heat gains. The series includes multiple sizes and nominal cooling capacities from 240,000 to 360,000 BTUH. Resistance heating elements are available in various wattages.

Industrial Climate Engineering models feature an exclusive electronic control board.

The control board consolidates several electrical components, improves the air conditioner's reliability and has LED's to indicate operating status and fault conditions to assist the service technician. A complete description of functions of the control board is in Section 1.6

Other standard components include:

- Hot gas by-pass valve provides for closer temperature control in mechanical cooling and protects against coil freeze-upduring low load conditions.
- Thermal expansion valve to improve both efficiency and capacity over a wide range of ambient temperatures
- Phase monitor to prevent operation if the unit is not properly phased and high/low voltage

ICE CFH units are designed for easy installation and service. Major components are accessible for service beneath external panels.

All units have internal disconnects. Depending upon state and local code requirements, this feature may eliminate the need for an external breaker or disconnect.

1.2 Model Identification

The model identification number is found on the data sticker. Rating plate located on side panel.

Example	С	F	Н	3	1	8	0	Α	D	0	5	0	D	R	Н	+	+	1	С	Α	+	Α	2	1	+	+	+	+	+	+
Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

1	Unit Designation/Family	C = Industrial Climate Engineering (ICE)							
2	Energy Efficiency Ratio (EER)								
3	, , ,	H = R-454B							
4	Refrigerant Type	3 = Dual							
-	Compressor Type/Quantity								
5	Unit Capacity/Nominal	240 = 240,000							
6	Cooling (BTUH)	300 = 300,000 360 = 360,000							
7 8	System Type	A = Air Conditioner							
0	System Type								
9	Power Supply (Volts-Hz-Phase)	A = 208/230-60-1 E = 380-50-3 (4 Wire) C = 208/230-60-3 M = 400-60-30 D = 460-60-3 Z = 575-60-3							
10	lus at Basis as in								
11	Heat Designation @ Rated Voltage	000 = No Heat 150 = 15KW 180 = 18KW							
	KW = Kilowatt	090 = 9KW							
12									
13	Ventilation Configuration	A = Solid Front Door C = Economizer D = Motorized Damper w/Pressure Relief E = Motorized Damper w/Pressure Relief & Independent Motorized Damper Control F = No Free Cooling, 100% Emergency Ventilation Only w/Independent Control							
14	Dehumidification	R = Electric Reheat T = Electric Reheat w/Humidity Control + = None							
15	Controls	F = PLC w/Summed Alarms H = PLC w/2-Stage Control 2 = PLC w/5-Stage Control + = None \$ = Special							
16	Operating Condition	A = Evaporator Freeze Sensor (EFS) C = EFS w/Hot Gas Bypass M = Extreme Duty w/Hard Start & EFS N = Hard Start P = Hard Start w/Low Ambient & CCH Q = Hard Start w/Low Ambient & Fan Cycle Control (FCC) R = Crank Case Heater (CCH) T = Hard Start w/EFS U = Hard Start w/EFS U = Hard Start w/Low Ambient & CCH & EFS W = Low Ambient w/CCH X = Hot Gas Bypass Y = Low Ambient w/CCH & FCC Z = Low Ambient w/CCH & EFS 1 = Low Ambient w/FCC 2 = Low Ambient w/FCC 2 = Low Ambient w/FCC 3 = CCH w/Hot Gas Bypass + = None							

Note: Not all options are available with all configurations. Contact your ICE sales representative for configuration details and feature compatibility.

17	Indoor Air Quality Features	A = UV Light D = Dry Bulb Sensor E = Dry Bulb Sensor w/Dirty Filter G = Dirty Filter Sensor K = Bi-Polar Ionization + = None						
18	Air Flow	1 = Top Supply/Center Return (STD) 2 = Center Supply/Top Return						
19	Compressor Location	C = Center						
20	Filter Option	A = 2" Pleated (MERV 8, AC/HP-C) C = 2" Charcoal D = MERV 11 High Filtration Package E = MERV 13 High Filtration Package F = Filter Access Through Return Air Opening G = F + C H = F + D J = F + E K = F + W W = Aluminum Washable + = None						
21	Corrosion Protection	A = Condenser Coil Only C = Evaporator Coil Only D = Both Coils Condenser & Evaporator E = All Coils Cond/Evap/Reheat F = Coat All K = Coastal Package + = None \$ = Special						
22	Engineering Revision Level	B2 C2						
24	Cabinet Color	1 = Marvair Beige (STD) 2 = Gray (STD) 3 = Carlsbad Canyon (STD) 4 = White (STD) 5 = Stainless Steel Exterior 9 = Pebble Gray A = Stainless Steel - Unit \$ = Custom Color (Powder Coat)						
25	Sound Attenuation	2 = Compressor Blanket + = None						
26	Security Option	A = Lockable Access Plate/Tamper Proof B = Lockable Latch/Hinge + = None						
27	Fastener/Drain Pan Option	A = Stainless Steel Fasteners C = Stainless Steel Drain Pan D = Stainless Steel Fasteners & Drain Pan + = None						
28	Special Variation	+ = None \$ = Special Configuration Not Covered by Model Nomenclature						
29	Unused	+ = None \$ = Special						
29		T Openial						

1.3 Serial Number Date Code

20 = 2020	01 = January	05 = May	09 = September
21 = 2021	02 = February	06 = June	10= October
22 = 2022	03= March	07 = July	11 = November
23 = 2023	04 = April	08 = August	12 = December

1.4 Weights and Filter Sizes

Electrical and performance specifications and dimensional drawings are in the Product Data Sheet.

Note: Follow local codes and standards when designing duct runs to deliver the required airflow. Minimize noise and excessive pressure drops caused by duct aspect ratio changes, bends, dampers and outlet grilles in duct runs.

Model Number	CFH3240	CFH3300	CFH3360
Cooling BTUH ¹	216,600	300,000	330,000
Rated Air Flow (CFM²)	7,400	11,900	10,200
ESP ³ @ Rated Conditions	0.40	0.45	0.55
Minimum Air Flow (CFM²)	5,920	9,520	8,160

¹Cooling rated at 95°F (35°C) outdoor and 80°F DB/67° WB (26.5°C DB/19.5°C WB) return air ²CFM=Cubic Feet per Minute ³ESP=External Static Pressure

Ratings are with no outside air. Performance will be affected by altitude.

Ratings are at 230 volts for 208/230 volt units ("C" models), 460 volts for "D" models, 380 volts for "E" models, 575 volts for "Z" models. Derate performance by 17% for ACE (380v. 3ø, 50 Hz) models. Operation of units at a different voltage from that of the rating point will affect performance and air flow.

Table 1. Cooling Performance and Air Flow Ratings

MODEL	Description	Inches	Millimeters	Part #	# of Filters	MERV Rating
CFH3180/3240	Exterior Access Return Air Filter	25 x 16 x 2	635 x 406 x 51	80137	4	8 (STD)
CFH3180/3240	Interior Access Return Air Filter	24 x 18 x 2	610 x 457 x 51	81257	4	8 (STD)
CFH3240 w/Economizer Fresh Air Hood Pre-filters		26 x 12 x 1	660 x 305 x 25	92526	2	N/A
CFH33240 Center Supply/ Top Return w/Economizer	Fresh Air Hood Pre-filters	16 x 32 x 1	406 x 813 x 25	93187	3	N/A
CFH3300/3360	Interior Access Return Air Filter	30 x 20 x 2	762 x 508 x 51	92545	4	8 (STD)
CFH3300/3360	Fresh Air Filter (Economizer Only)	15 x 26 x 1	381 x 660 x 25	92982	2	8 (STD)
CFH3300/3360 Center Supply/		33 x 40 x 2	838 x 1,016 x 51	93269	2	N/A

Table 2. Filter Sizes/Part Numbers

	Linit V	Voight	Ship	ping	Shipping Dimensions						
MODEL	Unit Weight		Weight		Height		Width		Depth		
	LBS	KG	LBS	KG	Inches	MM	Inches	MM	Inches	MM	
CFH3240	2,523	1,144	2,636	1,196	98	2,489	76	1,930	51	1,295	
CFH3300	2,625	1,193	2,750	1,250	108	2,743	72	1,829	72	1,829	
CFH3360	3,210	1,456	3,335	1,513	108	2,743	72	1,829	72	1,829	

Table 3. Shipping Weights & Dimensions

		CFH3240A	CFH3300A	CFH3360A
Minimum Boom Size (ft2)	Top Supply	259.2	424.2	408.4
Minimum Room Size (ft²)	Center Supply	508.7	832.4	801.6
Minimum Cumply Height (ft)	Top Supply	6.9	6.9	6.9
Minimum Supply Height (ft)	Center Supply	3.5	3.5	3.5

Table 4. Room Size Limitations

1.5 General Operation

Hot Gas By-Pass

Standard on all models except the, Hot Gas By-Pass is normally used in specialty applications (i.e Magnetic Resonance Imaging (MRI) buildings) to prevent magnetic voltage disturbance caused by cycling. This technology is applied in this product to extend the operation envelope for the compressor to 20° F (-6.6°C). Combined with a condenser low ambient Fan Cycle feature, compressor operation can be extended to 0° F (-17.8°C). During Hot Gas operation mode, system performance will be reduced. If product operation is in mild outdoor ambient conditions, the installed shut-off ball valve may be closed, thus disabling the Hot Gas By-Pass feature.

Refrigerant Cycle (Cooling Mode)

The air conditioners use R-454B refrigerant in a conventional vapor-compression refrigeration cycle to transfer heat from air in an enclosed space to the outside. A motorized impeller assembly blows indoor air across the evaporator. Cold liquid refrigerant passing through the evaporator is boiled into gas by heat removed from the air. The warmed refrigerant gas enters the compressor where its temperature and pressure are increased. The hot refrigerant gas condenses to liquid as heat is transferred to outdoor air drawn across the condenser by the condenser fan. Liquid refrigerant is metered with a thermal expansion valve (TXV) into the evaporator to repeat the cycle.

Economizer

The factory installed economizer saves energy and reduces the run time on the compressor and condenser fan motor by using outside air – when suitable – to cool the shelter.

Note: The economizer option is currently available on the 1120,1150, 3180, 3240, 3300 and 3360.

On a signal from the wall mounted indoor thermostat that cooling is required, either mechanical cooling with the compressor or free cooling with the economizer is provided. A factory installed enthalpy controller determines whether the outside air is sufficiently cool and dry to be used for cooling. If suitable, the compressor is locked out and the economizer damper opens to bring in outside air through fresh air hoods located on each side of the air conditioner. The outside air is filtered with filters in each of the outside air hoods. Integral pressure relief allows the interior air to exit the shelter, permitting outside air to enter the shelter. The temperature at which the economizer opens is adjustable from 63°F (17°C) at 50% Relative Humidity to 73°F (23°C) at 50% Relative Humidity.

After the enthalpy control has activated and outside air is being brought into the building, the mixed air sensor measures the temperature of the air entering the indoor blower and then modulates the economizer damper to mix the right proportion of cool outside air with warm indoor air to maintain 50°-63°F (10° - 17°C) air being delivered to the building. This prevents shocking the electronic components with cold outside air.

The compressor is not permitted to operate when the economizer is functioning.

If the outside air becomes too hot or humid, the economizer damper closes completely, or to a field selectable minimum open position, and mechanical cooling is activated.

Fresh air hoods with prefilters are field installed on each side of the air conditioner.

CFH (Dual Compressor) Units: The CFH is factory wired for maximum cooling utilizing both compressors. If 2 stage compressor operation is desired, the factory installed jumper between terminals 1 and 2 of the low voltage terminal strip must be removed. The 1st stage cooling input is terminal 1 of the low voltage terminal strip and the 2nd stage cooling input is terminal 2 of the low voltage terminal strip. The thermostat must be programmed for 2 stage cooling operation when 2 stage compressor operation is desired.

Heating Mode

A wall-mounted thermostat controls the heating cycle of models which incorporate resistance heating elements. On a call for heat, the thermostat closes the heat relay to energize the indoor fan and the resistance elements.

1.6 Programmable Logic Controller

MGA3090A-3180A models include a factory installed PLC to control the operation of the HVAC system The built-in PLC display screen shows operational status and provide assistance with diagnosis if troubleshooting is ever required. Various control functions are field selectable and programmable. The PLC is also capable of communicating to other PLCs to allow run time leveling and does not require additional equipment to be installed. The PLC provides improved reliability because of the reduction of components. The components utilized are more durable and the control box wiring has been simplified. Pertinent statistical data about the life of the refrigeration system can be accessed through the PLC.



Figure 1.
Programmable Logic Controller

The PLC is factory installed and tested, requires no adjustments or changes when the air conditioning system is installed.

Location

Remove the HVAC unit front access panel and open the panel door to the control cabinet. The PLC is located on the left side the low voltage section of the control box.

PLC Inputs & Outputs

Relay outputs can be located on the top of the PLC. The PLC has 1(Qty) Form C relay that is used as a common alarm output. All other outputs are used for Air conditioning operation. Along the bottom of the PLC, there are 7 banks of terminals, which represents 4 analog outputs, 8 digital inputs and 8 Analog inputs. The PLC also comes with communication interface for MODBUS RS485, BACnet MSTP, BACnet IP and MODBUS IP. A built in power supply is also integrated into the PLC for powering peripheral sensors.

See Appendix A for more PLC related information

1.7 Optional Controls & Packages

Protective Coating Packages

Coated Coils: Either the condenser or evaporator coil can be coated. For harsh conditions, e.g., power plants, paper mills or sites were the unit will be exposed to salt water, the coils should be coated. *Note:* Cooling capacity may be reduced by up to 5% on units with coated coils.

Coastal Environmental Package: This package includes:

- Corrosion resistant fasteners.
- Sealed or partially sealed condenser fan motor,
- Coating applied to all exposed internal copper and metal in the in the condenser section, and
- A protective coating on the condenser coil.

All Coat Package: Includes the same features as the Coastal Environmental Package and adds a coating on the evaporator coil and on all exterior and interior components and sheet metal. (**Note:** the insulated internal sheet metal and the internal control box are not coated).

Dirty Filter Indicator

A diaphragm type of indicator measures the air pressure on either side of the filter and when the pressure drops below the set point, a red LED is illuminated. The set point is adjustable.

Cabinet Color

ICE air conditioners are available in six different cabinet colors. The standard colors are Marvair® beige, white, gray and Carlsbad Canyon (brown). The standard cabinet's sides, top and front panels are constructed of 20 gauge painted steel. Contact your ICE representative for color chips. Custom colors are also available; contact ICE for details.

Two stainless steel cabinet constructions are available:

Stainless Steel Exterior (Option "5"): This option replaces all standard exterior painted surfaces with stainless steel. This option also replaces the standard unpainted compressor base of the unit and exterior cabinet screws with stainless steel. No other standard construction surfaces are stainless steel in this option, unless listed in this description. Back panel is not stainless steel with this option. This option is designed to give a more economical alternative to full stainless steel, and still offer an enhanced level of protection. For further corrosion protection, please see our "A" offering at full stainless on all metal components.

Stainless Steel Unit (Option "A"): This option replaces all interior and exterior steel sheet metal parts with stainless steel. All galvanized and painted steel surfaces found in the standard unit are stainless steel with this option. All cabinet screws are stainless steel. No other standard construction surfaces are stainless steel, unless listed in this description. This option is designed to give our most robust protection against steel corrosion.

Fresh Air Damper

Allows introduction of outside air into the building to provide positive pressurization. Field installed on either the left or right hand side of the unit. See Appendix A for installation instructions.

Model Number	Fresh Air Damper Part #	Fresh Air Damper Filter Part #	Fresh Air Damper Filter Size In (mm)						
CFH3240	K/04757-xxx	92127	9¼" x 37" x ¾" (235 x 940 x 10)						
CFH3300/3360	K/10169-xxx	92526	12" x 26" x 1" (305 x 660 x 25)						
xxx designates the color. 200 =	xxx designates the color. 200 = Grey (standard). 100 = Beige. 500 = Stainless Steel								

Crankcase Heater

Crankcase Heater Recommended for use for units installed in cold climates.

Dual Compressors With Lead/Lag Operation

Freeze Sensor On Indoor Coil

Prevents frost on the indoor coil caused by a loss of air flow or restrictive duct work.

Filter Access From Return Air Grille

Factory or field installed filter bracket allows changing and access to the filters from the return air grille. See model ID, special option code "I".

Center Supply/Top Return Configuration

Location of Supply and Return Air Openings are reversed.

1.8 Electrical Operation

The compressor and condenser fan are energized with a contactor controlled by a 24 VAC pilot signal. Some compressors incorporate an internal PTC crankcase heater that functions as long as primary power is available. The heater drives liquid refrigerant from the crankcase and prevents loss of lubrication caused by oil dilution. Power must be applied to the unit for 24 hours before starting the compressor. The condenser (outside fan) motor is energized by the same contactor.

The indoor evaporator fan motor is controlled by the fan purge on the electronic control board.

1.9 Leak Detection System

All models in this manual are equipped with a leak detection system. Once the unit is installed it must be powered, at all times, except for service. During normal operation the leak detection system has no impact on the operation of the unit, however upon detection of R-454B refrigerant all operations are stopped except for the indoor blower. The unit will then re-circulate air in the room for a minimum of 5 minutes. Once the 5 minutes have expired and the concentration of the refrigerant is below 8 percent of the Lower Flammability Limit (LFL) the unit will be allowed to operate as normal. If the concentration of the refrigerant remains above 8 percent of the LFL the unit will remain in re-circulation mode. To verify actuation of mitigation simply remove the sensor from the mitigation control board and the system should stop all operation except for the indoor blower. There is no need to calibrate or service the sensor. The sensor will provide an alarm upon failure or end of life. The sensor must be replaced with an identical sensor, or a manufacturer approved alternative.




Figure 2a. Typical Electrical Schematic - CFH3240A




Figure 2b. Typical Electrical Schematic - CFH3300A & CFH3360A

MARNING

Failure to observe and follow Warnings and Cautions and these Instructions could result in death, bodily injury or property damage. Read this manual and follow its instructions and adhere to all Cautions and Warnings in the manual and on the ICE unit.

2.1 Equipment Inspection

Concealed Damage

Inspect all cartons and packages upon receipt for damage in transit Remove cartons and check for concealed damage. **Important: keep the unit upright at all times.** Remove access panels and examine component parts. Inspect refrigerant circuit for fractures or breaks. The presence of refrigerant oil usually indicates a rupture. If damage is apparent, <u>immediately file a claim with the freight carrier.</u>

Units that have been turned on their sides or tops may have concealed damage to compressor motor mounts or to the oil system. If the unit is not upright, immediately file a claim for concealed damages and follow these steps:

- 1. Set unit upright and allow to stand for 24 hours with primary power turned on.
- 2. Attempt to start the compressor after 24 hours.
- 3. If the compressor will not start, makes excessive noise, or will not pump, return the unit to the freight carrier.

2.2 Installation Requirements

MARNING

Do not remove P-Trap Loop from condensate drain hose. P-Trap Loop must be primed at initial startup before unit is run.

General

- 1. Inspect unit for completeness. Check for missing parts (e.g. hardware). Refer to the installation kit information in section 2.3.
- 2. Remove access panels and check for loose wires. Tighten screw connections.
- 3. Complete and mail the warranty registration card.

You must consider all of the following when choosing the installation site:

- 1. **Noise.** Install the unit so that the least amount of noise will be transmitted to inhabited spaces.
- 2. <u>Condensate Drainage</u>. Condensate produced during operation must be discharged to a suitable drain.

3. Placement.

- A) Place the unit in a shaded area, if possible.
- B) Install it above ground for protection against flooding.
- C) The unit exhausts air. Be sure that the airflow is not impeded by shrubbery or other obstructions.
- D) When installing multiple units, please note the recommended clearances noted in Table 4.

CAUTION

CFH3240A, 3300A, 3360A units require additional support. The mounting flanges alone are not adequate.

4. Airflow Requirements:

This is maximum external static pressures for duct design. Duct pressure drop not to exceed these values.

Maximum Static Pressures	CFH3240	CFH3300	CFH3360
IWG	1.4	1.6	0.8
Pa	348	398	149

Keep duct lengths as short as possible. Do not obstruct airflow through the unit.

Duct work should be designed and installed in accordance with *all* applicable safety codes and standards. Industrial Climate Engineering strongly recommends referring to the current edition of the National Fire Protection Association Standards 90A and 90B *before* designing and installing duct work. The duct system must be engineered to insure sufficient air flow through the unit to prevent over-heating of the heater element. This includes proper supply duct sizing, sufficient quantity of supply registers, and adequate return and filter areas. Duct work must be of correct material and must be properly insulated. Duct work must be constructed of galvanized steel with a minimum thickness of .019 inches. Duct work must be firmly attached, secured, and sealed to prevent air leakage. See section 2.4 for additional duct work requirements.

Altitude (Meters)	Altitude (Feet)	Correction Factor
0	0	1.00
200	660	1.00
400	1310	1.00
600	1970	1.00
800	2620	1.02
1000	3280	1.05
1200	3940	1.07
1400	4590	1.10
1600	5250	1.12
1800	5910	1.15
2000	6560	1.18
2200	7220	1.21
2400	7870	1.25
2600	8530	1.28
2800	9190	1.32
3000	9840	1.36
3200	10500	1.40
3400	11150	1.45
3600	11810	1.50
3800	12470	1.55
4000	13120	1.61
4200	13780	1.67
4400	14440	1.72
4600	15090	1.79
4800	15750	1.85
5000	16400	1.92

In accordance with UL 60335-2-40, for units above 600m, multiply the minimum room area stated in the table above by the correction factor that corresponds with the altitude the unit is located at. This will give you a new minimum room area that is adjusted for your altitude. The units listed in this manual are not intended for use above 5000 meters.

Table 5. Altitude Correction Factor

5. Clearances:

Note the minimum clearances required for proper operation and service. There must be no obstruction 24" from the sides of the unit, or 120" from the front of the unit. Additional clearance is required in high ambient temperatures, greater than 120°F (49°C).

MODEL	MIN. CLEAREANCE AROUND SIDES (SINGLE UNIT)	MIN. CLEARANCE BETWEEN UNITS (TWO UNITS)	_	MIN. CLEARANCE TO FRONT OF UNIT
CFA3240	24 in. (61 cm)	24 in. (61 cm)	24 in. (61 cm)	120 in. (305 cm)
CFA3300/ CFA3360	96 in. (244 cm)	96 in. (244 cm)	24 in. (61 cm)	42 in. (107 cm)

Table 6. Minimum Clearances

6. Codes:

Make sure your installation conforms to all applicable electrical, plumbing, building, and municipal codes. Some codes may limit installation to single story structures.

7. Electrical Supply:

The power supply must have the appropriate voltage, phase, and ampacity for the model selected. Voltage must be maintained above minimum and below maximum specified values listed below. Refer to the data sticker on the unit for ampacity requirements.

Note: Operation near the Minimum or Maximum limits at extended periods voids the warranty. Power supply should be at nominal Voltage.

Electrical Rating Designations*	Α	С	D	Z
Nominal Voltage	208/230	208/230	460	575
Phase	1	3	3	3
Minimum Voltage	197	197	414	518
Maximum Voltage	253	253	506	632

^{*} Letters refer to model number code designations. Refer to page 5.

Table 7. Voltage Limitations

2.3 Installation Materials

The CFH may be shipped with a top bracket and optional lifting brackets. The top bracket provides a method of sealing the top of the unit from water intrusion. The bracket is shipped attached to the top of the unit. Before installing the unit, remove the bracket and reattach as described in Section 2.5

If ordred, the lifting brackets are shipped attached to the back panel of the unit. These brackets provide a method for lifting the unit. The installation of the brackets is described in Section 2.6.

Kit Components:

Accessories:

The package may include other factory-supplied items (optional):

P/N	Description
70705	CommStat 6 2/4 HVAC Controller, Solid State Lead/Lag Controller
S/12087-04	CommStat 6 4/8 HVAC Controller, Solid State Lead/Lag Controller
S/12087-06	CommStat 6 6/12 HVAC Controller, Solid State Lead/Lag Controller
S/07846	CommStat 4 HVAC Controller, Solid State Lead/Lag Controller
S/04581	CommStat 3 HVAC Controller, Solid State Lead/Lag Controller
50123	Digital thermostat. 1 stage heat, 1 stage cool. 7 day programmable. Fan switch: Auto & On. Auto-change over. Keypad lockout. Non-volatile program memory.
93189	Double Deflection Aluminum Supply Grille for the CFH1120/1150 & CFH3150 $42\frac{1}{2}$ x $15\frac{1}{4}$ (1,080mm x 387mm)
93188	Aluminum Return Filter Grille for the CFH1120/1150 & CFH3150 42½ x 21½ (1,080mm x 546mm)
93190	Double Deflection Aluminum Supply Grille for the CFH3180/3240/3300/3360 54½ x 15½ (1,384mm x 394mm)
93191	Aluminum Return Filter Grille for the CFH3180/3240 54½ x 21½ (1,384mm x 546mm)
93192	Aluminum Return Filter Grille for the CFH3300/3360 54½" x 37½" (1,384mm x 953mm)

Additional Items Needed:

Additional hardware and miscellaneous supplies (not furnished by ICE®) are needed for installation.

The list below has the items typically needed for mounting a unit on a wood frame wall structure. Concrete or fiberglass structures have different requirements. ICE cannot recommend a specific method of attaching the air conditioner to the building due to the wide variety of building types, code requirements, wall construction and specific installation conditions. The installation of the air conditioner to the building must take in to account all of these factors and follow best industry practices to provide a safe and secure attachment to the building.

- A properly sized external disconnect
- Mounting bolts for unit mounting flanges. The length needed is typically the wall thickness plus one inch (25 mm).
- Washers
- Hex nuts
- Silicone Sealer to seal around cracks and openings
- Minimum 5 conductor low voltage multicolored wire cable (i.e. thermostat wire)
- Appropriate electrical supplies such as conduit, electrical boxes, fittings, wire connectors, etc.
- High voltage wire, sized to handle the MCA (minimum circuit ampacity) listed on the data plate.
- Over-Current Protection Device sized in accordance with the MFS (maximum fuse size) listed on the unit data plate.

! WARNING FIRE HAZARD

Improper adjustment, alteration, service, maintenance or installation could cause serious injury, death and/or property damage.

Installation or repairs made by unqualified persons could result in hazards to you and others. Installation MUST conform with local codes or, in the absence of local codes, with codes of all governmental authorities have jurisdiction.

The information contained in this manual is intended for use by a qualified service agency that is experienced in such work, is familiar with all precautions and safety procedures required in such work, and is equipped with the proper tools and test instruments.

2.4 Porting and Duct Work

General Information

Note: The following instructions are for general guidance only. Due to the wide variety of installation possibilities, specific instructions will not be given. When in doubt, follow standard and accepted installation practices, or contact ICETM for additional assistance.

Wall Openings

Measure the dimensions of the supply and return ports on the unit.

Cut the openings in the exterior wall for the supply and return. **IMPORTANT:** All units with electric heat must have 1" (25.4mm) clearance on all four sides of the supply outlet duct flange on the unit. The 1" (25.4mm) clearance must extend on all sides of the supply duct for the first 3 feet (1 meter) from the unit.

IMPORTANT: ICE™ requires a minimum of 1" (25.4mm) from the surface of any supply ducts to combustible material for the first 3 feet (1 meter) of the duct.

Ducting

Extensions should be cut flush with the inside wall for applications without duct work.

Applications using duct work should be designed and installed in accordance with *all* applicable safety codes and standards. ICE strongly recommends referring to the current edition of the National Fire Protection Association Standards 90A and 90B *before* designing and installing duct work. The duct system must be engineered to insure sufficient air flow through the unit to prevent over-heating of the heater element. This includes proper supply duct sizing, sufficient quantity of supply registers, adequate return and filter area. Ductwork must be of correct material and must be properly insulated. Duct work must be constructed of galvanized steel with a minimum thickness of .019 inches for the first 3 feet (1 meter). Ductwork must be firmly attached, secured and sealed to prevent air leakage. Do not use duct liner on inside of supply duct within 4 feet (122cm) of the unit.

Galvanized metal duct extensions should be used to simplify connections to duct work and grilles. Use fabric boots to prevent the transmission of vibration through the duct system. The fabric must be U.L. rated to a minimum of 197°F (92°C).

Minimum Airflow Requirements

The duct system must be engineered to assure sufficient air flow through the unit even under adverse conditions such as dirty filters, etc.

2.5 Top Flange Installation (See Figure 2)

- 1. All models have built-in side mounting flanges.
- 2. Attach the top flange to the top of the air conditioner. The holes in the top of the air conditioner have been predrilled. Remove the 4 screws in these holes and use these screws to attach the top flange to the air conditioner.
- 3. Apply a bead of silicone sealer on the wall side of the bottom support brackets on the unit. Circle the mounting holes with the silicone bead.





Figure 3. Top Flange and Lifting Bracket Installation (Typical)

2.6 Installing the Optional Lifting Brackets

Lifting brackets are available which can be installed on the top of the side panels. These brackets allow the unit to be picked up using lifting eyes in the brackets. Attach the brackets to the left and right side panels as shown in Figure 3. ICE units are shipped with the 4 screws for attaching the brackets installed in the holes at the top of the side panels. When attaching the brackets, remove and reinstall the screws and make sure the top of the bracket is angled towards the center of the unit.

2.7 Mounting The Unit

- 1. For wiring into the back of unit, locate the lower of the two knockouts on the wall side of the unit. Drill a one inch hole in the shelter wall to match this opening. Allow sufficient clearance to run 3/4" conduit through the hole and to the unit.
- 2. Lift the unit into position using an appropriate and safe lifting device.
- 3. Make sure that the duct flanges are properly aligned with the wall opening. Adjust as necessary.
- 4. Note the holes in each side flange. Using the holes for guides, drill holes through the wall with a drill bit. Insert the bolts through the flanges. Install nuts and washers on the inside of the shelter. Tighten the bolts to secure the unit.
- 5. Apply a bead of silicone where the side and top flanges contact the exterior wall.
- 6. On the inside of the shelter, install the wall sleeves in the supply and return air openings. The sleeves may be trimmed to fit flush with the inside wall.
- 7. Check the fit of each sleeve to its mating flange for possible air leaks. Apply silicone sealer to close any gaps. Install the air return and supply grilles.



For units with electric heat, a one inch clearance is required around the duct extensions. The duct extensions must be constructed of galvanized steel with a minimum thickness of .019" as per the NFPA standards 90A & 90B.

Figure 4. Air Conditioner Wall Mount Detail

2.8 Compressor Chocks Removal

MARNING

Wooden compressor chocks must be removed and discarded when unit is at final shipping destination. If chocks are not removed damage to compressor or copper system may occur.

Final installer must remove wooden chocks from beneath compressors.

Remove screw from in front of wooden chock, pull chock out from underneath compressor and discard both screw and wooden chock.

Note: There are two chocks to be removed one in the front of the compressor and one at the back of the compressor.





Figure 5. Compressor Chock Removal

2.9 Unit Support Recommendations

Guidelines:

- 1. For units 15 tons and larger, the base of the unit should be fully supported in transit and in stationary applications to not allow deflection in static or dynamic loading.
- 2. For units ranging from 7.5 tons to 12.5 tons, the base of the unit should be fully supported in transit to not allow deflection in dynamic loading.
- 3. The supports should run perpendicular to the fork pockets on the base of the unit.
- 4. The fork pockets should remain in place for best support.
- 5. The supports should be 12" on center and include all outer edges.
- 6. The unit should be mechanically fastened to the support platform to not allow independent movement between the unit and its support.




Figure 6a Unit Compression Support Examples




Figure 6b Unit Tension Support Examples

This is a recommendation as it relates to best practices for supporting the unit. Understand that how the unit should be supported varies based on several factors such as available space, supporting structure (concrete, metal), application (static or dynamic) etc. We recommend that the structural integrity of the design be evaluated by a structural expert before integration into the design. Any decision on use of materials or geometry is the sole responsibility of the customer. Please be advised that supporting the unit along the entire base is required for proper logistics movement. Supporting the unit along the entire base is also required for in place operation on units 25 tons and larger.

2.10 Electrical Connections

↑ WARNING ELECTRICAL SHOCK HAZARD

Failure to follow safety warnings exactly could result in serious injury, death, and/or property damage.

Turn off electrical power at fuse box or service panel BEFORE making any electrical connections and ensure a proper ground connection is made before connecting line voltage.

↑ CAUTION

NOTICE TO INSTALLER/CONTRACTORS: This unit's internal control circuit/transformer is designed to power factory installed unit components only. Connecting external component loads may be done at your own risk of voiding the manufacturer's product warranty.

Important

All electrical work must meet the requirements of local codes and ordinances. Work should be done **only** by qualified persons.

The units may incorporate an internal crankcase heater for compressor protection. The crankcase heater must be energized for at least 24 hours prior to starting the compressor.

Scroll compressors, like several other types of compressors, will only compress in one rotational direction. The direction of rotation is not an issue with single-phase compressors since they will always start and run in the proper direction. However, three phase compressors will rotate in either direction depending upon phasing of power. Since there is a 50-50 chance of connecting power in such a way as to cause rotation in the reverse direction, it is imperative to confirm that the compressor is rotating in the proper direction at the initial field start-up of the system. Verification of proper rotation is made by observing that the suction pressure drops and the discharge pressure rises when the compressor is energized. An alternate method of verification for self contained system with small critical refrigerant charges, where the installation of gauges may be objectionable, can be made by monitoring the temperature of the refrigerant lines at the compressor. The temperature should rise on the discharge line while the suction line temperature decreases. Reverse rotation also results in a substantially reduced current draw when compared to tabulated values.

There is no negative impact on durability caused by operating three phase compressors in the reversed direction for a short duration of time, usually defined as less than one hour. However, after several minutes of operation the compressor's internal protector will trip. The compressor will then cycle on the protector until the phasing is corrected. Reverse operation for longer than one hour may have a negative impact on the bearings.

To change the rotation, turn off power to the unit and reverse L1 & L2 at the disconnect in the air conditioner.

The middle front panel provides access to the electrical/control box and to the filters. This panel has hinges on the left and right hand side. This panel should ONLY be opened by using the two hinges on the left side **OR** the two hinges on the right side. **NEVER OPENALL FOUR HINGES SIMULTANEOUSLY**.

If all four hinges are opened simultaneously, the front panel will drop and may cause serious injury and damage the panel.

⚠ DANGER

NEVER open all four hinges simultaneously. The panel should ONLY be opened by using the two hinges on the left side OR the two hinges on the right side.

High Voltage Wiring

The power supply should have the proper voltage, phase, and ampacity for the selected model.

1. Refer to the electrical data on the data sticker on the unit for field wiring requirements of the unit. Size the incoming power supply lines and the fuse(s) or HACR breaker(s) according to requirements described in the National Electric Code. Run the power conductors through the knockouts on the side or back of the unit. Use appropriate conduit and strain reliefs.

CAUTION

Note: Power supply service must be within allowable range (+10% - 5%) of rated voltage stamped on the unit rating plate. To operate nominal 230/208V unit at 208V, change the transformer line tap from 240V to 208V following the instruction on wiring label in unit.

- 2. Connect the wires to the input side of the internal breaker or terminal block L1, L2, & L3 for three-phase models.
- 3. Install the ground wire on the ground lug.
- 4. For units designed for operation on 208/230V, 60Hz power supply, the transformer is factory wired for a 230V power supply. For a 208V power supply, remove the orange lead from the transformer and connect the red lead. Insulate the orange lead.

A CAUTION

The external breaker(s) that provide power to the air conditioner must be sized per the maximum Fuse Size (MFS) shown on the Unit's data label.

Dual Unit Phasing

For applications where one controller operates two units, e.g., the CommStat 4.

- 1. Wire each unit as described in steps 1 through 4 above.
- 2. Test for proper phasing as follows:
 - A. Power up the units.
 - B. Using an AC volt meter set to the 300 volt scale, measure voltage between terminal L1 on the compressor contactor of unit #1 and terminal L1 on the compressor contactor of unit #2 If voltage is present, units are wired out of phase and must be rewired.
 - C. If units are not in phase, turn off power and reverse the field power leads connected to the internal circuit breaker on one of the units only.
 - D. Restore power and retest the phase (step B). When the voltage reads "0", the units are in phase.
 - E. Turn off power and proceed.

Low Voltage Wiring

IMPORTANT. The following instructions are generic wiring instructions and may not be applicable for air conditioners with various options. Always refer to the wiring diagram in the air conditioner for the proper method to wire your unit.

- 1. On single units, pull the low voltage wiring (e.g., 18 gauge 4-conductor Class 2 thermostat wire) from the air conditioners into the thermostat / subbase assembly. See Figure 4a for connections to various thermostats.
- 2. Mount the thermostat on the wall of the shelter. The thermostat should be located so that the supply air from the unit does NOT blow directly on to the thermostat. Connect the thermostat to the terminal block in the air conditioner as shown in Figure 6a.
- 3. On dual units, refer to either the ICE CommStat 3 or CommStat 4 *Controller Specification sheet*. Wire the two air conditioners to the Lead/Lag Controller, according to the wiring diagram on the specification sheet.

Remote Signalling: Terminals 5 & 7(N.O.) and 6 & 7 (N.C.) on the air conditioners terminal board are dry contacts which can be used for remote signalling in the event of a/c cutoff on low or high pressure limit.

Continuous fan operation: For continuous indoor fan operation on single units, install a jumper between terminals 8 and 3.

CommStat 4 Lead /Lag HVAC Controller

Please refer to the Product Data sheet for the CommStat 4 controller for complete instructions on installing and programming this controller.




Figure 7a. Humidistat Wiring to a Marvair Air Conditioner with Reheat.




Figure 7b. CommStat 4 Connection Diagram

Chapter 3 Start-Up

3.1 Check-Out of Cooling Cycle

Important: Be sure that the crankcase heater (if used) has been energized for at least 24 hours before starting the unit(s). Double-check all electrical connections before applying power. All air conditioners with scroll compressors running on 3Ø power must be checked for proper rotation during the initial start-up. Please refer to Section 2.8 for determining if the 3Ø compressors are rotating correctly. Incorrect rotation can damage the compressor and is not covered by the warranty

Procedure:

- 1. Set the cooling set point temperature on the wall thermostat to a point *higher* than the ambient temperature. Set the heating set point temperature to a temperature that is *lower* than the ambient.
- 2. Set the thermostat system switch in the AUTO position. Nothing should operate at this time.
- 3. Set the time delay in the control box to three minutes. See Section 1.6.
- 4. Slowly lower the thermostat's cooling set point temperature until the switch closes. The indoor fan should operate.
 - Once the indoor fan turns on, allow approximately three minutes for the compressor to start.
- 5. To stop cooling, slowly raise the thermostat cooling set point to a temperature higher than the ambient.

If the unit fails to operate, refer to the troubleshooting information in Chapter 4.

Follow the same procedure for additional units.

NOTE: The fan purge allows the indoor fan to run for approximately 90 seconds after the compressor is off. This operation provides a small improvement in system rated efficiency.

3.2 Check-Out of Heating Cycle

Procedure: (Applies only to units with resistance elements)

- 1. Raise the heating set point temperature to a setting which is higher than the ambient temperature. The fan and electric heat should immediately cycle on.
- 2. Move the system switch to the "OFF" position. All functions should stop.

Chapter 4 Troubleshooting

4.1 Overview

The middle front panel provides access to the electrical/control box and to the filters. This panel has hinges on the left and right hand side. This panel should ONLY be opened by using the two hinges on the left side **OR** the two hinges on the right side. **NEVER OPENALL FOUR HINGES SIMULTANEOUSLY**.

If all four hinges are opened simultaneously, the front panel will drop and may cause serious injury and damage the panel.

M DANGER

NEVER open all four hinges simultaneously. The panel should ONLY be opened by using the two hinges on the left side OR the two hinges on the right side.

A comprehensive understanding of the operation of the air conditioner is a prerequisite to troubleshooting. Please read the Chapter 1 for basic information about the unit.

Our air conditioners are thoroughly tested before they are shipped from the factory. Of course, it is possible that a defect may escape undetected, or damage may have occurred during transportation. However, the great majority of problems result from installation errors.

If you experience difficulties with the unit, please review the installation steps in Chapter 2.

Much time can be saved by taking a thoughtful and orderly approach to troubleshooting. Start with a visual check - are there loose wires, crimped tubing, missing parts, etc? Begin deeper analysis only after making this initial inspection.

The troubleshooting information in this manual is basic. The troubleshooting section contains problem/solution charts for general problems, followed by a compressor section.

Not every problem can be anticipated. If you discover a problem that is not covered in this manual, we would be very grateful if you would bring it to the attention of our service department for incorporation in future revisions.

As always, please exercise caution and good judgement when servicing the air conditioner. Use only safe and proven service techniques. Use refrigeration goggles when servicing the refrigeration circuit.

↑ WARNING

The refrigerant circuit has hot surfaces, and the electrical voltages inside of the unit may be hazardous or lethal. SERVICE MAY BE PERFORMED <u>ONLY</u> BY QUALIFIED AND EXPERIENCED PERSONS.

4.2 Failure Symptoms Guide

PROBLEM/SYMPTOM	LIKELY CAUSE(S)	CORRECTION
A. Unit does not run.	1. Power supply problem.	Check power supply for adequate phase and voltage. Check wiring to unit and external breakers or fuses.
NOTE: An internal anti-short-cycle	2. Tripped internal disconnect.	2. Check internal circuit protection devices for continuity.
timer will prevent the unit from starting for .2 to 8 minutes following start-up.	Shut off by external thermostat or thermostat is defective.	3. Check operation of wall-mounted thermostat.
mindes following start up.	4. Unit off on high or low pressure limit.	4. Reset pressure switch.
	5. Internal component or connection failure.	5. Check for loose wiring. Check components for failure.
B. Unit runs for long periods or continuously; cooling is insufficient.	Dirty filter or reduced airflow	Check air filter(s). Check blower operation. Remove airflow restriction.
	2. Low refrigerant.	2. Check for proper charge and possible refrigerant leak.
	3. Component failure.	Check internal components, especially compressor for proper operation.
	4. Unit undersized for job.	4. Add additional units for greater capacity.
C. Unit cycles on high/low pressure limit.	1. Loss or restriction of airflow.	Check blower assembly for proper operation. Look for airflow restrictions, e.g., the air filter. Check blower motor and condenser fan.
	2. Restriction in refrigerant circuit.	Check for blockage or restriction, especially filter drier and capillary tube assembly.
	Refrigerant overcharge (following field service)	3. Evacuate and recharge to factory specifications.
	4. Defective pressure control.	Check limit cutout pressures. Control is set to actuate at approximately 60 PSIG (low pressure) and 650 PSIG (high pressure)
D. Unit blows fuses or trips circuit breaker.	Inadequate circuit ampacity.	Note electrical requirements in Chapter 2 and correct as necessary.
	2. Short, loose, or improper connection in field wiring.	2. Check field wiring for errors.
	Internal short circuit. Loose or improper connection(s) in unit.	Check wiring in unit. See wiring and schematic diagrams. Test components (especially the compressor) for shorts.
	4. Excessively high or low supply voltage or phase loss (3ø only)	4. Note voltage range limitations specific to the compressor troubleshooting section.
E. Water on floor near unit.	Obstruction in condensate line.	1. Check for clog or restriction.
	Obstruction or leak in condensate pan.	2. Check pan for leak or blockage.
	3. Unit is not level.	3. Level unit.
F. No space heating or reduced heating	Defective heating element(s).	Check resistance element(s) for continuity.
(units equipped with resistance ele- ments)	2. Thermal limit open.	2. Check continuity across thermal limit switch.
	3. Defective heater contactor.	3. Check relay for proper operation. Replace if defective.

4.3 Compressor Troubleshooting

NOTE: It is important to rule out other component failures before condemning the compressor.

The following electrical tests will aid diagnosis:

- 1. **Start-Up Voltage**: Measure the voltage at the compressor contactor during start-up. The voltage must exceed the minimum shown in Table 5, section 2.2, or compressor failure is likely. A low voltage condition must be corrected.
- 2. **Running Amperage**: Connect a clip-on type ammeter to the (common) lead to the compressor. Turn on the supply voltage and energize the unit. The compressor will initially draw high amperage; it should soon drop to the RLA value or less. If the amperage stays high, check the motor winding resistances.

NOTE: Feel the top of the compressor to see if it has overheated. If it is hot, the internal overload may be open. You may have to wait several hours for it to reset.

3. **Motor Winding Resistances:** Using a digital volt-ohm meter (VOM), measure the resistance across the compressor windings as shown below.

SINGLE C THREE T₁
PHASE
$$R_2$$
 R_3 R_2 R_1
 R_3 R_2 R_3 R_4 R_5 $R_$

Resistance can be measured as shown above. Any deviation from above values could indicate a defective compressor.

- 4. **High Voltage/Insulation Test:** Test internal leakage with a megohmeter. Attach one lead to the compressor case on a bare metal tube and to each compressor terminal to test the motor windings. A short circuit at high voltages indicates a motor defect. <u>Do not</u> do this test under vacuum.
- 5. On single phase models, check the capacitor by substitution.

4.4 Control Board Diagnosis

The control board (see section 1.6 for a complete description of the control board) has a red diagnostic LED which indicates the lockout fault. The control board will enter into and indicate lockout if either of the fault conditions (LPS or HPS) occur twice.

The compressor contactor must be closed before the first fault condition can be recognized by the control board. The contactor will be closed 3 minutes after the unit is energized and only if cooling is required. The first fault condition will open the contactor and shutdown the unit. The contactor on the unit that has the fault condition must be closed before the second fault condition can be recognized by the control board. The compressor contactor on the unit with the fault condition will close after 3 minutes if the unit is still calling for cooling and if the fault condition no longer exists. If you get a second fault condition, the contactor will open and shutdown the unit. The "red" led will have one blink if the high pressure switch has opened twice and will have two blinks if the low pressure switch has opened twice. The unit must be in the cooling mode (compressor contactor Closed) before a fault condition can occur.

Chapter 5 Maintenance & Repair

The middle front panel provides access to the electrical/control box and to the filters. This panel has hinges on the left and right hand side. This panel should ONLY be opened by using the two hinges on the left side **OR** the two hinges on the right side. **NEVER OPENALL FOUR HINGES SIMULTANEOUSLY**.

If all four hinges are opened simultaneously, the front panel will drop and may cause serious injury and damage the panel.

⚠ DANGER

NEVER open all four hinges simultaneously. The panel should ONLY be opened by using the two hinges on the left side OR the two hinges on the right side.

5.1 Scheduled Maintenance

Industrial Climate Engineering strongly recommends that the air conditioner be serviced a minimum of twice a year – once prior to the heating season and once prior to the cooling season. At this time the filters, evaporator coil, condenser coil, the cabinet, and condensate drains should be serviced as described below. Also at this time, the air conditioner should be operated in the cooling and heating cycles as described in Chapter 3, Start-Up. In addition to this seasonal check-out, the air conditioner should be maintained as follows:

Air Filter

Replace the air filter whenever it is visibly dirty. Never operate the unit without the filter in place. Depending upon the configuration of your unit, access to the filter can be either from the outside through the hinged door or from the return grille on the inside of the building.

Evaporator

If the evaporator becomes clogged or dirty, it may be cleaned by careful vacuuming or with a commercial evaporator cleaning spray. DO NOT use a solvent containing bleach, acetone, or flammable substances. Turn off power before cleaning. Be careful not to wet any of the electrical components. Be sure the unit has dried before restarting.

Condenser

Periodically inspect the outdoor condenser coil and the cabinet air reliefs for dirt or obstructions. Remove foreign objects such as leaves, paper, etc.

If the condenser coil is dirty, it may be washed off with a commercial solvent intended for this purpose. TURN OFF POWER BEFORE CLEANING! Be sure that all electrical components are thoroughly dry before restoring power. Use a fin comb of the correct spacing to straighten mashed or bent fins.

Cabinet

The cabinet may be cleaned with a sponge and warm, soapy water or a mild detergent. Do not use bleach, abrasive chemicals or harmful solvents.

Drains

The condensate is drained from the condensate pan through two drains – one on the left side of the pan and the other on the right side. The condensate lines drain to the outside at the bottom of the unit through the base pan. Each of the drain lines is looped to form a trap.

Regularly check each drain line to make sure it is not obstructed. If a commercial drain solvent is used, flush out the drain pan and system with sufficient water to remove the solvent. Some solvents can cause the drain pan to corrode.

Lubrication

The condenser fan motor(s) and the evaporator blower motor(s) never require oiling.

5.2 Repair

IMPORTANT

All procedures shall be performed by trained personnel with a certificate from a manufacturer or national training agency that is accredited to teach the relevant national competency standards.

Switching off the appliance or opening of the enclosure has a significant effect on the safety. Care should be taken to ensure sufficient ventilation before.

- 1. Portable equipment shall be repaired outside or in a workshop specially equipped for servicing units with FLAMMABLE REFRIGERANTS.
- 2. Ensure sufficient ventilation at the repair place.
- 3. Be aware that malfunction of the equipment may be caused by refrigerant loss and a refrigerant leak is possible.
- 4. Discharge capacitors in a way that won't cause any spark. The standard procedure to short circuit the capacitor terminals usually creates sparks.
- 5. Reassemble sealed enclosures accurately. If seals are worn, replace them.
- 6. Portable equipment shall be repaired outside or in a workshop specially equipped for servicing units with FLAMMABLE REFRIGERANTS.
- 7. Ensure sufficient ventilation at the repair place.
- 8. Be aware that malfunction of the equipment may be caused by refrigerant loss and a refrigerant leak is possible.
- 9. Discharge capacitors in a way that won't cause any spark.
- 10. When brazing is required, the following procedures shall be carried out in the following order:
 - Safely remove the refrigerant following local and national regulations. If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. In doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
 - Purge the refrigerant circuit with oxygen free nitrogen.
 - Evacuate the refrigerant circuit.
 - Purge the refrigerant circuit with nitrogen for 5 min (not required for A2L refrigerants).
 - Evacuate again (not required for A2L refrigerants).
 - Remove parts to be replaced by cutting or brazing.
 - Purge the braze point with nitrogen during the brazing procedure required for repair.
 - Carry out a leak test before charging with refrigerant
- 11. Reassemble sealed enclosures accurately. If seals are worn, replace them.
- 12. Check safety equipment before putting it into service.

5.3 Pre-Checks

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.

The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:

- the actual REFRIGERANT CHARGE is in accordance with the room size within which the refrigerant containing parts are installed.
- the ventilation machinery and outlets are operating adequately and are not obstructed.
- if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant.
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected.

• refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

Repair and maintenance of electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment, so all parties are advised.

Initial safety checks shall include:

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking.
- that no live electrical components and wiring are exposed while charging, recovering or purging the system.
- that there is continuity of earth bonding.

Sealed electrical components shall be replaced. Sealed components are designed to prevent the ingress of explosive gases or dust by being enclosed in a protective housing. They ensure that any potential ignition source is contained within the sealed environment. Sealed enclosures protect electrical equipment from dust, moisture, and corrosive environments while also preventing the ignition of any gases or vapors within the enclosure.

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also consider the effects of aging or continual vibration from sources such as compressors or fans.

Chapter 6 Service and Charging/Recovery

IMPORTANT

All procedures shall be performed by trained personnel with a certificate from a manufacturer or national training agency that is accredited to teach the relevant national competency standards.

6.1 Service

Prior to beginning work on systems containing FLAMMABLE REFRIGERANTS, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the REFRIGERATING SYSTEM, the following shall be completed prior to conducting work on the system.

- 1. Work shall be undertaken under a controlled procedure to minimize the risk of flammable gas or vapor being present while the work is being performed.
- 2. All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided
- 3. The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection
- 4. If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area.
- 5. No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- 6. Ensure that the area is open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

The minimum test pressure for the low side of the system shall be the low side design pressure and the minimum test pressure for the high side of the system shall be the high side design pressure, unless the high side of the system, cannot be isolated from the low side of the system in which case the entire system shall be pressure tested to the low side design pressure.

6.2 Leak Detection

When flammable refrigerants leak, they can form vapors that are heavier or lighter than air, depending on the specific refrigerant. Accumulation in enclosed spaces increases explosion risk. If a flammable vapor-air mixture reaches its LFL and encounters an ignition source, it can lead to an explosion. This can cause serious damage to property and pose risks to personnel. Common ignition sources include electrical sparks, open flames, and electric heaters. The presence of flammable refrigerants can lead to rapid combustion if these sources are not controlled. Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used. The following leak detection methods are deemed acceptable for all refrigerant systems. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a

potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipework. NOTE Examples of leak detection fluids are

- 1. Bubble method
- 2. Fluorescent method agents

If a leak is suspected, all naked flames shall be removed/extinguished. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

6.3 Charging Procedures

	CFH3240A	CFH3300A	CFH3360A
Refrigerant Charge (oz.)	264	432	416

Table 8. Refrigerant Charge (R-454B, Ounces)

Charging procedures - In addition to conventional charging procedures, the following requirements shall be followed.

- 1. Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- 2. Cylinders shall be kept in an appropriate position according to the instructions.
- 3. Ensure that the REFRIGERATING SYSTEM is earthed prior to charging the system with refrigerant.
- 4. Label the system when charging is complete (if not already).
- 5. Extreme care shall be taken not to overfill the REFRIGERATING SYSTEM.
- 6. Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

6.4 Refrigerant Recovery

When removing refrigerants from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely. When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:

- 1. Safely remove refrigerant following local and national regulations.
- 2. Evacuate.
- 3. Continuously flush or purge with inert gas when using flame to open circuit
- 4. Open the circuit
- 5. The REFRIGERANT CHARGE shall be recovered into the correct recovery cylinders. For appliances containing FLAMMABLE REFRIGERANTS other than A2L REFRIGERANTS, the system shall be purged with oxygen-free nitrogen to render the appliance safe for FLAMMABLE REFRIGERANTS. This process may need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.
- 6. For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum

- (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place
- 7. The outlet for the vacuum pump shall not be close to any potential ignition sources, and
- 8. Ventilation shall be available.
- 9. When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- 10. The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant. If in doubt, the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.
- 11. The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- 12. If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.

Chapter 7. Commissioning, Decommissioning and Disposal

IMPORTANT

All procedures shall be performed by trained personnel with a certificate from a manufacturer or national training agency that is accredited to teach the relevant national competency standards.

7.1 Commissioning

- 1. Ensure that the floor area is sufficient for the REFRIGERANT CHARGE or that the ventilation duct is assembled in a correct manner.
- 2. Connect the pipes and carry out a leak test before charging with refrigerant.
- 3. Check safety equipment before putting into service

7.2 Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task commences.

- a. Become familiar with the equipment and its operation
- b. Isolate the system electrically.
- c. Before attempting the procedure, ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders.
 - all personal protective equipment is available and being used correctly.
 - the recovery process is supervised at all times by a competent person.
 - recovery equipment and cylinders conform to the appropriate standards.
- d. Pump down the refrigerant system, if possible.
- e. If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f. Make sure that cylinder is situated on the scales before recovery takes place.
- g. Start the recovery machine and operate in accordance with instructions.
- h. Do not overfill cylinders (no more than 80 % volume liquid charge).
- i. Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j. When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k. Recovered refrigerant shall not be charged into another REFRIGERATING SYSTEM unless it has been cleaned and checked.

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

- 1. If the safety is affected when the equipment is putted out of service, the REFRIGERANT CHARGE shall be removed before decommissioning.
- 2. Ensure sufficient ventilation at the equipment location.

- 3. Be aware that malfunction of the equipment may be caused by refrigerant loss and a refrigerant leak is possible.
- 4. Discharge capacitors in a way that won't cause any spark.
- 5. Remove the refrigerant. If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. In doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
- 6. When FLAMMABLE REFRIGERANTS except A2L REFRIGERANTS are used,
 - Evacuate the refrigerant circuit.
 - Purge the refrigerant circuit with nitrogen for 5 min.
 - · Evacuate again.
 - Fill with nitrogen up to atmospheric pressure.
 - Put a label on the equipment that the refrigerant is removed.

7.3 Disposal

National regulations should be followed when disposing of equipment using flammable refrigerants.

- 1. Ensure sufficient ventilation at the working place.
- 2. Remove the refrigerant. If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. In doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
- 3. When flammable refrigerants are used,
 - evacuate the refrigerant circuit.
 - purge the refrigerant circuit with oxygen free nitrogen.
 - evacuate again. (not required for A2L refrigerants); and
 - cut out the compressor and drain the oil.
- 4. Cut out the compressor and drain the oil.

Chapter 8 Warranty

8.1 Industrial Climate Engineering Limited Product Warranty

Marvair Inc., warrants its products to be free from defects in materials and workmanship under normal use to the original purchaser for the period of time in the table below. If any part of your product fails within 12 months from start-up, or 18 months from shipment from the factory, whichever comes first, Marvair, Inc. will furnish without charge, EXW Cordele, Georgia, the required replacement part. The owner must provide proof of the date of the original start-up. The contractor's invoice, the certificate of occupancy, or similar documents are examples of acceptable proof of the date of the original start-up.

Marvair, ICE, Eubank Products 90 Days¹ w/Flat Rate Labor² (See Marvair, ICE, Eubank Flat Rate Labor Guidelines) 1 Year Parts²,³ 5 Years Compressor²

The responsibility of the equipment owner includes:

- 1. To operate the equipment in accordance with the manufacturer's instructions.
- 2. To provide easy accessibility for servicing.
- 3. To check and reset any circuit breaker(s) and/or disconnect(s) prior to calling for service.
- 4. To keep the unit clean and free of dirt and containment and replace filters as required.
- 5. To keep the outdoor coil clean and free of leaves, paper, or other debris.
- 6. To pay the charges incurred when any of the above have not been done.
- 7. To pay for repair or replacement of any material or part other than those within the Marvair unit or controller.

Marvair, Inc., will not be responsible for labor after 90 days, transportation costs, delays or failures to complete repairs caused by events beyond our control (labor hours incurred due to required site-specific training, time waiting to gain access, or extended drive time for remote sites). This warranty does not cover:

- Any transportation, related service labor, diagnosis calls, filter, driers, refrigerant, or any other material charges.
- 2. Damages caused by shipping, accident, abuse, negligence, misuse, fire, flood, or Acts of God.
- 3. Damages caused by operating or staging the unit in a corrosive environment.
- 4. Damages caused by improper application of the product.
- 5. Damages caused by failing to perform proper routine maintenance.
- 6. Expenses incurred for erecting, disconnecting or dismantling the product or installing the replacement part(s).
- 7. Products not installed or operated according to the included instructions, local codes, and good trade practices.
- 8. Products moved from the original installation site.
- 9. Products lost or stolen
- 10. Consequential damages or incidental expenses including losses to persons, property or business.
- 11. Modifications to original unit after it leaves the factory, such as breaking into any part of the sealed systems unless authorized in advance in writing by Marvair, Inc..
- 12. Damages as a result of operating as a construction site cooler / dehumidifier.

When labor (first 90 days only) is required, it must be performed during normal working hours (8:00 AM - 5:00 PM) Monday - Friday and must be performed by Marvair, Inc., personnel or a designated Service Representative.

The owner of the product may ship the allegedly defective or malfunctioning product or part to Marvair, Inc., at such owner's expense, and Marvair, Inc., will diagnose the defect and, if the defect is covered under this warranty, Marvair, Inc., will honor its warranty and furnish the required replacement part. All costs for shipment and risk of loss during shipment of the product to Marvair, Inc., and back to the owner shall be the responsibility and liability of the owner. Upon written request by an owner, Marvair, Inc., may arrange for remote diagnosis of the allegedly defective or malfunctioning product or part but all costs for transportation, lodging and related expenses with regard to such diagnostic services shall be the responsibility and liability of the owner.

An owner requesting performance under this Warranty shall provide reasonable access to the allegedly defective or malfunctioning product or part to Marvair, Inc., and its authorized agents and employees.

THIS WARRANTY CONSTITUTES THE EXCLUSIVE REMEDY OF ANY PURCHASER OF A MARVAIR HEAT PUMP OR AIR CONDITIONER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR USE, TO THE FULLEST EXTENT PERMITTED BY LAW. IN NO EVENT SHALL ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR USE EXCEED THE TERMS OF THE APPLICABLE WARRANTY STATED ABOVE AND MARVAIR SHALL HAVE NO OTHER OBLIGATION OR LIABILITY. IN NO EVENT SHALL MARVAIR BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OR MONETARY DAMAGES.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE-TO-STATE. Some states do not allow limitations or exclusions, so the above limitations and exclusions may not apply to you.

¹If any part of your Marvair, Inc. unit fails within 90 days of the commencement of the warranty, Marvair, Inc. will furnish without charge, EX Works, Cordele, Georgia, the required replacement part and pay for the labor to replace the part in accordance with the Marvair, Inc. Flat Rate Labor Guidelines.

²ALL OTR (over the road) applications that are moved from one location to another: Factory Warranty applies only up to the point of initial start-up and test at all OEM manufacturing locations or subsequent facility. Once it goes into OTR service, the warranty expires immediately for compressor and sealed system components. This OTR exemption does not apply to relocatable classrooms, construction or office trailers.

³All warranty replacement parts shall be shipped Ground only. Expedited shipping is available upon request for additional cost.

Chapter 9 Start-Up Check List

The middle front panel provides access to the electrical/control box and to the filters. This panel has hinges on the left and right hand side. This panel should ONLY be opened by using the two hinges on the left side **OR** the two hinges on the right side. **NEVER OPENALL FOUR HINGES SIMULTANEOUSLY**.

If all four hinges are opened simultaneously, the front panel will drop and may cause serious injury and damage the panel.

M DANGER

NEVER open all four hinges simultaneously. The panel should ONLY be opened by using the two hinges on the left side OR the two hinges on the right side.

9.1 Start-Up & Commissioning Form

Please complete the information on this form and return to ICE by mail or fax. The mailing address and fax number can be found at the end of the form.

A. Equipment Informatio	n				
Date:	Equipment Owner				
Installing Company: _		Installer:			
		State			
ICE Air conditioner:	Model No				
10211110011111					
Compressor:					
-					
Compressor:	Model No.				
B. Pre-Start Up					
Is there any shipping da	amage?		□Yes □No		
If so, where?					
Will this damage preve			□Yes □No		
Check Power Supply, d	oes it agree with data st	icker on air conditioner?	□Yes □No		
Has the ground wire be	en connected?		□Yes □No		
Has the circuit protection	on been sized and instal	led properly?	□Yes □No		
Controls					
Are the thermostat cont	rol wiring connections	made and checked?	□Yes □No		
Are all wiring terminals (including main power supply) tight?					
If unit has a crankcase	heater, has it been energ	ized for 24 hours?	□Yes □No		
On a 208/230 v. units is	s control transformer (24	4 AC) wired for correct voltage?	□Yes □No		

Condensate Section										
Has water been placed in	Has water been placed in drain pan to confirm proper drainage?									
Are correct filters in place	Are correct filters in place?									
Refrigerant Piping										
If leaks are found, repor	t any leaks to ICE Warranty Se	ervice Dept.								
C. Check Rated Voltage at Termin	nal Block for Imbalance befo	ore starting of Unit.								
□208/230V 1 Phase	□208/230V 3 Phase	□ 460V 3 Phas	e							
□380V 3 Phase 50Hz.	□575 3 Phase 60 Hz.									
Measured Line to Line Volts	s L1&L2V. L1&	&L3V.	L2&L3V.							
(L1&L2 + L1&L3 + L2&L3)	3)/3 = Avg. Voltage =									
Max. Deviation from avg. v	oltage =volt	s								
Voltage imbalance = (100 x)	Max. Deviation)/avg. Voltage	=%								
9	than 2% with the unit running the compressor to overheat ar									
Example: <u>Ma</u>	ximum Deviation from Averag Average voltage		Percent)							
Measured Voltages:										
L1 & L2 = 24		X7 1.								
L1 & L3 = 24	43 Volts = $717 / 3 = 239$ Avera	ige Voltage								

Three phase units only check fan & compressor rotation.

100 x 6/239 = 2.5% Voltage Unbalance

L2 & L3 = 233 Volts

 $239 - 233 = \underline{6}$

D. Heating Mode Check & Record Readings

	Circuit 1	Circuit 2 (if applicable)
Room Temperature		
Outside Temperature		
Evap. Entering Air DB Temp		
Evap. Entering Air WB Temp		
Evap. Leaving Air DB Temp		
Evap. Leaving Air WB Temp		
Heater Contactor Amps (L1)		
Heater Contactor Amps (L2)		
Heater Contactor Amps (L3)		
E. Cooling Mode Check & Record Refrigerant Pressures		
Recheck voltage imbalance in cooling mode:		
Measured Line to Line Volts L1&L2V.	L1&L3	V. L2&L3V.
(L1&L2 + L1&L3 + L2&L3)/3 = Avg. Voltage =		
Max. Deviation from avg. voltage =	_volts	
Voltage imbalance = (100 x Max. Deviation)/avg. Vol	tage =	0%

After 10 minutes of compressor operation, record the following:

	Circuit 1	Circuit 2 (if applicable)
Room Temperature		
Outside Temperature		
Suction Pressure		
Suction Line Temperature		
Discharge Pressure		
Discharge Line Temperature		
Entering Condenser Air		
Leaving Condenser Air		
Evap. Entering Air DB Temp		
Evap. Entering Air WB Temp		
Evap. Leaving Air DB Temp		
Evap. Leaving Air WB Temp		
Compressor Amps (L1)		
Compressor Amps (L2)		
Compressor Amps (L3)		
Notes:		


Appendix A: PLC SetUp and Operation

These instructions are intended to assist users in navigating through the different PLC screens as well as understanding the variables located on each screen.

Note:

- 1. Screen numbers are referenced from "Digital Inputs" which is the first screen seen when PLC's display is populated.
- 2. Normal mode represents the state in which there are no active faults and no user emergency functionality is triggered.

Navigation



The keys can be programmed from the controller application. In the following table are described the keys default setting (keys are configurable through the logic controller.

Each control can be adjusted by using the directional buttons. Note: In "Edit Mode", the cursor flashes under the value that is going to be modified by the user.

No.	Key	Press Once (press and release)			
1	 ∆ UP Scroll Up Increase/Modify a Value 				
2	 ▼ DOWN Scroll Down Decrease/Modify a Value 				
3	 RIGHT Move Cursor Right In Edit Mode Back to Next Menu/Page 				
4	< LEFT	Move Cursor Left In Edit Mode Go Back to Previous Menu/Page Press and Hold to Exit Edit Mode Without Saving			
5	ок	Enter/Exit Edit Mode Confirm Operation			

Digital Inputs

This screen correlates each PLC's digital input to the specific input that is being monitored. It also provides the status of each input. This drastically expedites troubleshooting which consequently decreases downtime of the unit. The "Digital Input" is the first screen that will populate on the PLC's display when the PLC has loaded.

Figure 1 shows the digital input screen when all pressure switches are properly functioning, and the emergency shutdown is closed.




Figure 1

Table 1 shows the designations for each input and their status based on the input.

Digital Input	Designation	Normal Status	Fault Status
1	HPS_1 [HIGH PRESSURE - CIRCUIT 1]	OK [CLOSED]	FAULT [OPEN]
2	LPS_1 [LOW PRESSURE - CIRCUIT 1]	OK [CLOSED]	FAULT [OPEN]
3	HPS_2 [HIGH PRESSURE - CIRCUIT 2]	OK [CLOSED]	FAULT [OPEN]
4	LPS_1 [HIGH PRESSURE - CIRCUIT 2]	OK [CLOSED]	FAULT [OPEN]
Al6*	EMS [SHUTDOWN/USER INTERLOCK]	OK [CLOSED]	FAULT [OPEN]

Table 1

Note that pressure faults only affect the operation of the respective circuit.

Operational Request

This screen maps each thermostat input to a digital input on the PLC. The state of each input is monitored which gives the end user the ability to see what operation is being requested by the controller (Thermostat, Lead/Lag, etc).

Figure 2 shows the operation request screen when stage 1 cooling is being requested.




Figure 2

Table 2 shows the designations for each input and their status based on the input.

Digital Input	Designation	Active	Inactive
5	Y-REQ [STAGE 1 COOLING REQUEST]	ON	OFF
6	Y2-REQ [STAGE 1 COOLING REQUEST]	ON	OFF
7	G-REQ [FAN ONLY REQUEST]	ON	OFF
8	W2-REQ [HEATING REQUEST]	ON	OFF


Table 2


"COOL_OP" represents the setting on the PLC which allows the HVAC unit to operate with a different number of cooling stages.

- 1. **2 Fixed Compressor**—This allows the unit to operate with 2 independent cooling stages. Therefore, allows the stages to be turned on as needed which effective provides a more optimal management of the temperature of the space being cooled. (Default)
- 2. 5 Stages This allows the compressor to operate with 5 stages of cooling. Note that HVAC unit must be equipped with necessary compressors and associated controls for this work. A indicator is Character "15" of model number is "2" for units with this capability.

Digital Output

These screens show the status of each digital output as well as a description of the respective output.





Note: In normal operation, the status of "DO8" is "OFF". If "DO8" is "ON" all outputs are turned off.

Psychrometrics 1|2

This screen monitors some air conditioning of the indoor and outdoor air as well as provide the user with the ability to calibrate these numbers with the adjacent respective offset.






Table 3 shows the description of each variable displayed on screen above.

Variable	Description		
RA ¹ TEMP	Space Temperature measured		
RA ¹ HUM	Space Humidity measured		
SA TEMP	Supply Air Temperature		
OA ² TEMP	Outdoor Temperature measured		
OA ² HUM Outdoor Humidity measured			
MA TEMP	Mixed Air Temperature measured		
¹ RA = Room Air ² OA = Outside Air			


Table 3

Note:

- 1. "SA TEMP" and "MA TEMP" are the same in most designs unless specified otherwise.
- 2. "OA TEMP", "OA HUM" and SA TEMP are only monitored in units with Economizers.

Motor Operation


This screen allows the end user to configure the operation of the air movers in the HVAC unit.



- 1. FAN STATUS This setting manages the indoor motor operation.
 - b. AUTO (Default) This setting allows the indoor blower to run based on a request for an air conditioning operation. Once the operation terminates, the blower goes off after the 90 second time off delay.
 - c. ON—This setting forces the blower to run continuously irrespective of an air conditioning operation. The blower operation only terminates if and emergency shutdown input is triggered.
- 2. IBM SPEED % The speed at which the PLC is commanding the indoor fan motor to operate.
- **3. OFM SPEED %** The speed at which the PLC is commanding the condenser fan to operate at.
- **4. OFM SPEED SP** This setting forces outdoor motor to operate at a speed designated by the user. Note that this is only applicable if the outdoor motor being used is an EC motor and "*HEAD PRES. CTRL*" is set to "*CYC*". (Default to 80%)
- **5. HEAD PRES. CTRL** This allows the end user to either modulate the outdoor fan or cycle the outdoor fan to manage the head pressure of the HVAC unit.
 - a. *MOD* (*Default*) Allows the condenser fan to modulate based on Head Pressure. As the head pressure rises, the condenser fan increases and vice versa. The system modulates to maintain a liquid line temperature of approximately 80 85°F.
 - b. CYC Allows the condenser fan to cycle on at the speed set a "OFM SPEED SP". The fan operates in an ON/OFF manner to maintain a liquid line temperature of about 90 95°F on average.
- **6. Control Signals** This allows the end user to set the control signal for motors. These are factory configured and should not be changed. If configured incorrectly, it will result in the motors not operating. IBM and OFM represents the options for the Indoor Blower Motor and Outdoor Fan Motor respectively.
 - g. 0-10VDC (Default for IBM) Set to be PWM for units 6 Tons and smaller
 - h. WM (Default for OFM)

IBM SPEED

This allows the end user to set the operational speed of the Indoor Blower Motor for each air conditioning operation. If the unit is only 2 stages, "STG 2" represents first stage cooling speed and "STG 5" represents second stage cooling speed.



Default Values:

Cooling (%)

Stage 1: 50

Stage 2: 55 (1st Stage Speed – 2 Fixed Compressor Setting. See "COOL_OP")

Stage 3: 60

Stage 4: 60

Stage 5: 65 (2nd Stage Speed– 2 Fixed Compressor Setting. See "COOL OP")

Heating (%)


Stage 1: 60

Fan Only (%)

Stage 1: 60

ECONOMIZER SETUP

This allows the end user to configure the economizer operation. See *Sequence of Operation* for in depth explanation of the function




- 1. **COOLING FUNC** Allows the selection of the various cooling approach.
 - b. *MECH* Mechanical Cooling (DX) Only. Cools space by activating the compressors without allowing infiltration of outside air.
 - c. ECON Basic Economizer. Attempts to Cools space initially by allowing infiltration of outside air without operating the compressor first. Activates compressor and a stop the infiltration of outside air if outside air cannot manage the heat load.
 - d. P. ECON (Default) Partial Economizer. Attempts to Cools space initially by allowing infiltration of outside air without operating the compressor first. Activates compressor as well as continue to allow infiltration of outside air to manage the heat load.

- 2. SENSOR TYPE Allows the selection of the parameters necessary for economizer operation.
 - c. Dry-bulb
 - d. Enthalpy
 - e. Dewpoint (Default)
- **3. TEMP SETPOINT** Temperature Differential required between the space and the outside air at which economizing is allowed. (Default = 70.0°F)
- **4. ENTHALPY SETPOINT** Enthalpy Differential required between the space and the outside air at which economizing is allowed. (Default = 50%)
- **5. DEWPOINT SP.** Dewpoint Setpoint is maximum dewpoint required between the space and the outside air at which economizing is allowed. (Default = 55°F)
- **6. STATUS** This tells if the HVAC unit is economizing or not.
 - a. ON Economizing
 - b. OFF Not economizing

DAMPER SETUP


Allows the end user to configure and monitor damper operation



- 1. MANUAL DMP Allows user to control the position of the damper manually
 - b. OFF (Default) Dampers are controlled automatically
 - c. ON Damper goes to the position configured in "DMP Pos (Man)".
- **2. DMP MODULATION** Allows the selection of modulation during economizing or go to a fix position configured in "*DMP Pos (Man)*".
 - c. AUTO (Default) Modulates to maintain a 55°F supply air temperature
 - d. MAN Damper position dictated by "DMP Pos (Man)".
- 3. **DMP_Pos** (Man) Allows the end user to define a position for the Damper. Note that immediate operation is dependent on previous settings. (Default = 0)
- 4. **DMP MIN POS** % Minimum allowed damper position (Default = 20%)
- 5. **DMP MAX POS** % Maximum allowed damper position (Default = 55%)
- **6. DMP ACT POS.** Requested damper position.
- 7. Control Signal Response tuning values. Tuned at factory. DO NOT CHANGE
 - a. Propotional Value (KP) = -37.2 (Default)
 - b. Integral Value (I) = 90 (Default)

REFRIGERATION


Allows the user to the monitor the liquid line temperature of each refrigeration circuit as well as offset the measured values.



- 1. H. PRESS A|B represents the liquid line temperature of circuit 1 and 2 respectively.
- **2. S. PRESS** A|B represents the suction pressure of circuit 1 and 2 respectively. (Not monitored) *Note:* The system modulates to maintain a liquid line temperature of 100°F.

THERMOSTAT (T-STAT)

This screen allows end users to setup the onboard thermostat. Note that this is only applicable if the associated sensors are purchased with the device. Note that Thermostat only works if a local sensor is purchased with the HVAC unit.




- **1. MODE** This allows the end user to select the allowable operation on the thermostat. See *Sequence of Operation* for explanation of the operation.
 - b. *OFF* (Default) Does not allow cooling, heating or dehumidification based on the sensor values measured. These operations can only be triggered by digital inputs. See digital inputs above for the respective inputs.
 - c. COOL This setting only allows cooling operation only.
 - d. HEAT This setting will only allow heating operation only.
 - e. AUTO This setting will allow both cooling and heating operation to occur.
- 2. COOL_SP—This variable represents the reference value used for triggering the cooling operation. (Default = 75°F)
- **3. COOL_DIF** This variable represents the allowable differential between each stage of cooling. For example. If [*COOL_SP* = 80 and *COOL_DIF* = 2], First Stage is triggered at 80, and second stage would be triggered at 82. (Default = 4°F)
- **4. HEAT_SP** This variable represents the reference value used for triggering the heating operation. (Default = 60°F)
- **5. HEAT_DIF** This variable represents the allowable differential between each stage of Heating. For example. If [*HEAT_SP* = 50 and *HEAT_DIF* = 2], First Stage is triggered at 50, and second stage would be triggered at 48. (Default = 4°F)

6. Humidity

- **a. HUMIDITY_SP** This variable represents the reference value used to trigger the dehumidification operation. (Default = 50%)
- **b. EN** This variable allows the end user to Enable or Disable the dehumidification operation. Note that this is unit dependent and supporting utility should be capable of supporting the full load capacity of the HVAC unit. See SPPE value on data label.
 - i. ON (Default) = Enabled
 - ii. OFF = Disable

COMMUNICATION SETUP

This screen allows end user to setup up some communication parameters. Note that the IP address set here is the IP address of the device and the address that would be used to access the local web server on the PLC. [DEFAULT VALUES SHOWN ON SCREEN ILLUSTRATION BELOW]



1. REMOTE CONFIG

- b. OFF Allows the IP address to be configured locally
- c. ON Allows the IP address configuration to be configured remotely

Web Server Default Credentials

Username: *administrator* Password: *marvair01*

Use the IP address in any web server while connected to the PLC via Ethernet to access the local web server on the PLC. Note that the PLC and the device being used to access the webserver MUST be on the same subnet for the user to gain access.

PLC GENERAL PURPOSE INPUT/OUTPUT

Analogue Input							
Name	Variable	Туре					
AIL1	Liquid Line Temp – Circuit 1	NTC					
AIL2	Liquid Line Temp – Circuit 2	NTC					
AIL3	Outdoor Air Temperature	VOLTAGE [0-10VDC]					
AIL4	Outdoor Air Humidity	VOLTAGE [0-10VDC]					
AIL5	Mixed Air Temperature	NTC					
AIL6	Emergency Shutdown Input	BOOL [N.C]					
AIL7	Dirty Filter	BOOL [PLC GND]					
AIL8	Dehumidification	BOOL [PLC GND]					
	Analogue Output						
Name	Variable	Туре					
AOL2	DAMPER MOTOR SIGNAL	0-10VDC					
AOL3	OUTDOOR MOTOR SIGNAL	PWM/0-10VDC					
AOL4	INDOOR MOTOR SIGNAL	PWM/0-10VDC					
	Digital Input						
Name	Variable	Туре					
DIL1	HIGH PRESSURE SWITCH 1 [HPS1_INPUT]	BOOL [24 VAC]					
DIL2	LOW PRESSURE SWITCH 1 [LPS1_INPUT]	BOOL [24 VAC]					
DIL3	HIGH PRESSURE SWITCH 2[HPS2_INPUT]	BOOL [24 VAC]					
DIL4	LOW PRESSURE SWITCH 2 [LPS2_INPUT]	BOOL [24 VAC]					
DIL5	COOL REQUEST 1 [Y_INPUT]	BOOL [24 VAC]					
DIL6	COOL REQUEST 2 [Y2_INPUT]	BOOL [24 VAC]					
DIL7	BLOWER REQUEST [G_INPUT]	BOOL [24 VAC]					
DIL8	HEATER REQUEST [W2_INPUT]	BOOL [24 VAC]					
	Digital Output						
Name	Variable	Туре					
DOL1	HEATER CONTACTOR	BOOL [24 VAC]					
DOL2	OUTDOOR MOTOR RELAY	BOOL [24 VAC]					
DOL3	INDOOR MOTOR RELAY	BOOL [24 VAC]					
DOL4	COMPRESSOR 1 CONTACTOR	BOOL [24 VAC]					
DOL5	COMPRESSOR 1 STAGE 2	BOOL [24 VAC]					
DOL6	COMPRESSOR 2 CONTACTOR	BOOL [24 VAC]					
DOL7	COMPRESSOR 1 STAGE 2	BOOL [24 VAC]					
DOL8	LOCK OUT RELAY	BOOL [24 VAC]					

Appendix B: PLC Sequence of Operation

Equipment should go through a commissioning/start up sequence recommended by manufacturer to ensure safety and system reliability. This document is only valid if the system is used as intended.

This document defines the manner and method of control of the system. It will cover the following operations and protections.

0.0 – Fan Operation

- ∘ 0.1 On Mode
- ∘ 0.2 Auto Mode

1.0 - Cooling Operation

- 1.1 Mechanical Cooling Only
- 1.2 Economizer Operation
 - Economizer Enable Modes
 - Standard Economizer
 - Partial Economizer

2.0 – Heating

∘ 2.1 – Electric Heat

3.0 –Refrigeration Protection

- ∘ 3.1 High Pressure Lockout
- ∘ 3.2 Low Pressure Lockout
- 3.3 Anti-Short Cycle Function
- \circ 3.4 Emergency Shutdown

4.0 – Dehumidification

• 4.1 – Electric Heat Dehumidification

5.0 – User Enabled Protection

- ∘ 5.1 Emergency Shutdown
- 5.2 Emergency Ventilation

Equipment, devices, and necessary system components are specified in the respective section.

Note:

- 1. All inputs on the Controller goes through a 5 second Time-On Delay to prevent nuisance request. Outputs go through a 5-10 second staggered Time On delay to prevent nuisance tripping of breaker due to the inrush associated with inductive loads.
- 2. Normal Operating Mode describes a mode in which there are no active faults which would interrupt the operation of the system.

0.0 - Fan Operation

0.1 - On-Mode

Indoor Blower Motor Runs continuously.

0.2 - Auto Mode

Indoor Blower Motor runs when there is a request for Cooling, Heating or Dehumidification and continues to run for 90 Seconds after the request is satisfied. When using the built-in thermostat, the indoor fan comes on 10F below the setpoint and continues to run until 90 seconds after the respective condition is satisfied. This function is only applicable with the Marvair designed sensor. Off-the-shelf thermostat operates based on a request for blower (G signal).

1.0 - Cooling Operation

1.1 - Mechanical Cooling Only

This section will describe the sequence of operation which takes place during Direct Expansion (DX) cooling with the OA dampers at their minimum position.

In normal operating mode, a request for "Stage 1 Cooling (Y-input)" via communication (BACnet or MODBUS), Digital Input or Onboard Thermostat, energizes the Indoor Blower Motor and Compressor 1 relay outputs on the PLC continuously. The controller also provides analog outputs (PWM or 0-10VDC Signal) associated to the Indoor Motor. In Stage 1 Cooling operation, the compressor and the indoor fan remains on continuously but the outdoor fan cycles based on head pressure. The Fan Cycle Control Switch (Low Ambient Control) closes at approximately 400 PSI to bring on the outdoor fan and reopens at approximately 290 PSI to turn the outdoor fan motor off. The described operations remain active until the Cooling Setpoint is satisfied (Stage 1 request drops out).

If the temperature continues to increase pass the defined setpoint [Cooling Setpoint + Cooling Differential], Stage 2 Cooling is energized. This energizes the Compressor 2 Output along with maintaining all previous outputs for Stage 1 Cooling. This output remains energized until the thermostat's Cooling Setpoint is satisfied. Once the setpoint is satisfied, the Compressor and the Outdoor fan outputs are de-energized. The indoor fan continues to operate of 90 sec

Note: This process describes the functionality with both an "off-the-shelf" thermostat and built-in thermostat.

1.2 - Economizer Operation

In Economizer mode, there are multiple process variables that are monitored and used to trigger Economizer operation. The process variables that are monitored are Outdoor Air Temperature (OAT), Outdoor Air Dewpoint (OAD) and Outdoor Air Enthalpy (OAE). The desired economizer option for control can be selected from the display on the PLC or via BACnet. The available options are described below.

- 1. <u>DRY-BULB FUNCTIONALITY</u>: (Default): [TOAT < TEconomizer Setpoint]ENTHALPY AND DEWPOINT ARE DESREGARDED
- 2. <u>ENTHALPY FUNCTIONALITY:</u> [OAE< Enthalpy Calculate] Uses [OAT + Humidity Setpoint] to calculate an enthalpy for operation.
- 3. OA Dewpoint Lockout (Enable/Disable): [OADewpoint < OADewpoint Lockout User Defined] and [TOAT < TEconomizer Setpoint] Uses [OAT + Humidity Setpoint] to calculate the dewpoint for operation.

When there is a request for "Stage 1 Cooling" and the outdoor conditions are satisfactory (based on selected mode of operation), the HVAC unit functions as follows.

Standard Economizer

1. Using- On-Board Thermostat

If economizer enable setpoint is satisfied, the Economizer Damper modulates to maintain the Room Temperature. If Room Temperature increases "20F" above the Cooling Setpoint, the system energizes the first compressor. Once the compressor is energized, the OA dampers close to the minimum position. If the Room temperature continue to rise above the [Cooling Setpoint + Cooling Differential (User Defined)], the system then energizes the second compressor/cooling stage if applicable. During this mode, supply air temperature will operate

between 55°F and 60°F. The cooling stages remain energized until the Cooling Setpoint is satisfied. Note that in this mode, the economizer and the compressor CANNOT operate simultaneously.

2. Using Off-the-shelf Thermostat

If economizer enable setpoint is satisfied, the Economizer Damper modulates to maintain the Room Temperature. During this mode, supply air temperature will operate between 55°F and 60°F. If the economizer process is not sufficient to meet the cooling requirement, the thermostat energizes the second stage output which forces the HVAC unit into full capacity. Once the compressor(s) are energized, the OA dampers close to the minimum position. The cooling stages remain energized until the Cooling Setpoint is satisfied. Note that in this mode, the economizer and the compressor CANNOT operate simultaneously.

Note: If the economizer enable setpoint is not satisfied, the economizer closes to its minimum position and mechanical cooling is used to cool the space.

2.0 – **Heating**

2.1 – Electric Heat

When there is a request for "Heating (W2)" via communication (BACNET or MODBUS), Digital Input or On-board Thermostat, the HVAC unit will run the Indoor Motor for 10 seconds prior to energizing the Heater Output. Once the Heater output is energized, the Heater comes "On" at full capacity (no staging). The Heater will remain "On" until the Heating setpoint is satisfied. Note that the heater and indoor motor are interlocked in software which means that only a heating request is required.

3.0 – Refrigeration Protection

3.1 - High Pressure Lockout

This condition describes the abnormal rise in Head Pressure pass the system acceptable limit of approximately 660 PSI (+/- 10 PSI). The fault will only be active when the High-Pressure Switch (Normally Closed) opens during a request for Cooling. The first time this fault condition occurs, the system cuts the compressor off WITHOUT locking out. Once the pressure normalizes (drops below 450 PSI), the system will resume operation if the cooling call still exist. If this fault occurs a second time on the same Cooling request, the system locks out. Lockouts can be monitored at lockout contacts in the system, via BACnet or MODBUS or on the display on the PLC. After this lockout condition is reached, the cooling call must be cycled or the system must be power cycled to clear the fault. The system will maintain the lockout until the problem is rectified.

3.2 - Low Pressure Lockout

This condition describes the abnormal fall in Suction Pressure below approximately 45 PSI (+/- 10 PSI). This fault will only be active when the Low-Pressure Switch (Normally Closed) opens during a request for Cooling. The Low-Pressure Switch is bypassed on the initial call for cooling for 3 minutes to allow low ambient start-up of the system. Once these 3 minutes have elapsed, if the switch is still open, the system cuts off the compressor. Once the pressure normalizes, the system will restart the cooling operation. If the fault occurs a second time on the same call for cooling, the system locks out. To clear the fault, the Cooling request must be cycled or the system must be power cycled. The system will continue to lockout unit the problem is rectified.

3.3 – Anti-Short Cycle

This is a built-in protection mechanism that increases the reliability of the compressor by protecting it from excessive short cycling. When the compressor goes off, due to any fault, emergency or if the cooling setpoint is satisfied, a built-in 3-minute timer locks the compressor out.

3.4 Emergency Shutdown

This condition is customer triggered. It can be done by opening the EMS-input on the PLC or triggered from BACnet. If this circuit is opened, all outputs are immediately terminated. That is, all dampers close completely and all motors immediately go off. If this input remains open, the system will not run. The display on the PLC provides the status of all inputs on the PLC.

4.0 – Dehumidification

4.1 – Electric Heat Dehumidification

Dehumidification mode needs to be Enabled on the PLC for this functionality to work. The Dehumidification mode has the lowest priority and will only be executed after the Cooling or Heating setpoints are met. Dehumidification request can also be triggered via BACnet. If the dehumidification functionality is enabled and the space humidity is greater than the dehumidification setpoint (User Defined), the HVAC unit will run the Indoor Motor, Stage 1 Compressor Only and the Electric Heat Simultaneously.

5.0 - User Enabled Protection

5.1 – Emergency Shutdown

This operation is customer triggered. It can be done by opening the EMS-input on the PLC or triggered from BACnet. If this circuit is opened, all outputs are immediately terminated. That is, all dampers close completely and all motors immediately go off. If this input remains open, the system will not run. The display on the PLC provides the status of all inputs on the PLC.

5.2 – Emergency Ventilation

This operation is customer triggered. When the respective input is set to the on-state, the HVAC controller terminates all air-conditioning processes and runs the indoor motor. If Emergency Ventilation and Emergency Shutdown are active simultaneously, Emergency ventilation takes priority. That is, the indoor motors would continue to operate while all air-conditioning operation is terminated.

Appendix C: PLC MODBUS Variables

Address	Name	Data Type	Default	Min	Max	Access Level	Description
8965	Y_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COM- PRESSOR 1 - STAGE 1 COOLING REQUEST (INPUT)
8966	Y2_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COM- PRESSOR 2 - STAGE 1 COOLING REQUEST (INPUT)
8967	G_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING INDOOR BLOWER REQUEST (INPUT)
8969	IBM_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING INDOOR BLOWER REQUEST (OUTPUT)
8970	OFM_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING OUTDOOR FAN REQUEST (OUTPUT)
8971	CC1_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COM- PRESSOR 1 - STAGE 1 COOLING REQUEST (OUTPUT)
8972	CC2_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COM- PRESSOR 2 - STAGE 2 COOLING REQUEST (OUTPUT)
8973	HEATER1_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING HEATING REQUEST (OUTPUT)
8977	LOI_MEM1	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COMMON LOCKOUT ALARM (OUTPUT)
8978	LPS1_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING CIRCUIT 1 LOW PRESSURE SWITCH (INPUT)
8979	LPS2_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING CIRCUIT 2 LOW PRESSURE SWITCH (INPUT)
8980	HPS1_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING CIRCUIT 1 HIGH PRESSURE SWITCH (INPUT)
8981	HPS2_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING CIRCUIT 2 HIGH PRESSURE SWITCH (INPUT)
8982	EMS_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING EMER- GENCY SHUTDOWN CONTACT (INPUT)
8983	SHORT_CYCLE_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING ANTI- SHORT CYCLE FOR COMPRESSOR CIRCUIT 1
8985	W2_MEM	Boolean	0			READ	MEMORY LOCATION FOR MONITORING HEATING REQUEST (OUTPUT)
8986	LOCKOUT_LPS1	Boolean	0			READ	MEMORY LOCATION FOR MONITORING CIRCUIT 1 LOW PRESSURE SWITCH LOCKOUT
8987	LOCKOUT_LPS2	Boolean	0			READ	MEMORY LOCATION FOR MONITORING CIRCUIT 2 LOW PRESSURE SWITCH LOCKOUT
8988	LOCKOUT_HPS1	Boolean	0			READ	MEMORY LOCATION FOR MONITORING CIRCUIT 1 HIGH PRESSURE SWITCH LOCKOUT
8989	LOCKOUT_HPS2	Boolean	0			READ	MEMORY LOCATION FOR MONITORING CIRCUIT 2 HIGH PRESSURE SWITCH LOCKOUT
8990	LOCKOUT_EMS	Boolean	0			READ	MEMORY LOCATION FOR MONITORING EMER- GENCY SHUTDOWN LOCKOUT
8999	Y_MEM_STG2	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COM- PRESSOR 1 - STAGE 2 COOLING REQUEST (INPUT)
9000	Y2_MEM_STG2	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COM- PRESSOR 2 - STAGE 2 COOLING REQUEST (INPUT)
9001	CC1_STG2	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COM- PRESSOR 1 - STAGE 2 COOLING REQUEST (OUTPUT)
9002	CC2_STG2	Boolean	0			READ	MEMORY LOCATION FOR MONITORING COM- PRESSOR 2 - STAGE 2 COOLING REQUEST (OUTPUT)

Address	Name	Data Type	Default	Min	Max	Access Level	Description
9003	IBM_OffDelay	Real	1			READ/WRITE	MEMORY LOCATION FOR SETTING INDOOR MOTOR TIME OFF DELAY
9005	ECON_HumSP	Real	0			READ/WRITE	MEMORY LOCATION FOR SETTING OUTDOOR HUMIDITY ENABLE (ONLY APPLICABLE IF LOCATION "9090" IS SET TO "0")
9007	ECON_MAS_scaled	Real	0			READ	MEMORY LOCATION FOR MONITORING THE MIX/ SUPPLY AIR TEMPERATURE
9009	ECON_ORH_scaled	Real	0			READ	MEMORY LOCATION FOR MONITORING THE OUTDOOR AIR RELATIVE HUMIDITY
9011	ECON_STATUS	Boolean	0			READ	MEMORY LOCATION FOR MONITORING THE STATUS OF THE ECONOMIZER
9013	SHORT_CYCLE_ MEM_2	Boolean	0			READ	MEMORY LOCATION FOR MONITORING ANTI- SHORT CYCLE FOR COMPRESSOR CIRCUIT 2
9016	Cool_SP	Real	0			READ/WRITE	MEMORY LOCATION FOR SETTING COOLING SET- POINT (APPLICABLE IF INTERNAL THERMOSTAT IS USED)
9019	Tstat_Mode	Signed 16-bit	0			READ/WRITE	0:OFF, 1:COOL, 2:HEAT, 3:AUTO (ONLY WORKS IF SENSOR IS INSTALLED IN UNITS)
9020	Tstat_Cool	Boolean	0			READ	MONITORS STATUS OF TSTAT MODE [IF EQUAL TO 1 - TSTAT MODE IS COOL ONLY]
9021	Tstat_Heat	Boolean	0			READ	MONITORS STATUS OF TSTAT MODE [IF EQUAL TO 1 - TSTAT MODE IS HEAT ONLY]
9022	Tstat_Auto	Boolean	0			READ	MONITORS STATUS OF TSTAT MODE [IF EQUAL TO 1 - TSTAT MODE IS COOL OR HEAT ONLY]
9023	Tstat_Off	Boolean	0			READ	MONITORS STATUS OF TSTAT MODE [IF EQUAL TO 1 - TSTAT MODE IS OFF]
9024	Heat_SP	Real	0			READ/WRITE	MEMORY LOCATION FOR SETTING HEATING SET- POINT (APPLICABLE IF INTERNAL THERMOSTAT IS USED)
9034	Cool_DIf	Signed 16-bit	0	2		READ	MEMORY LOCATION FOR SETTING COOLING DIF- FERENTIAL (APPLICABLE IF INTERNAL THERMO- STAT IS USED)
9035	Heat_DIf	Signed 16-bit	0	2		READ	MEMORY LOCATION FOR SETTING HEATING DIF- FERENTIAL (APPLICABLE IF INTERNAL THERMO- STAT IS USED)
9036	HUM_SP	Signed 16-bit	0			READ	MEMORY LOCATION FOR SETTING HUMIDITY SETPOINT (APPLICABLE IF INTERNAL THERMO- STAT IS USED)
9037	HUM_CTRL	Boolean	0			READ/WRITE	0 : DISABLES DEHUMIDIFICATION CONTROL , 1 : ENABLES DEHUMIDIFICATION CONTROL
9038	RemoteShutdown	Boolean	0			READ/WRITE	0 : ALLOWS NORMAL OPERATION , 1 : TRIGGERS EMERGENCY SHUTDOWN
9039	RoomHumScaled	Real	0			READ	MONITORS SPACE HUMIDITY
9041	RoomTempScaled	Real	0			READ	MONITORS SPACE TEMPERATURE
9045	Temp2Scaled	Real	0			READ	MONITORS OUTDOOR TEMPERATURE
9047	Temp2_Offset	Real	0			READ/WRITE	OFFSET VALUE FOR OUTDOOR TEMPERATURE
9049	SHORTCYCLETIME	Signed 16-bit	0			READ/WRITE	MEMORY LOCATION FOR SETTING ANTI-SHORT CYCLE TIME
9050	HumidityOffset	Signed 16-bit	0			READ/WRITE	OFFSET VALUE FOR SPACE HUMIDITY
9056	TStat_G_Op	Boolean	0			READ/WRITE	0: INDOOR FAN RUNS ON AUTO, 1: INDOOR FAN RUNS CONTINOUSLY
9059	RoomTemp1_Offset	Real	0			READ/WRITE	ALLOWS USER TO CALIBRATE THE MEASURED ROOM TEMPERATURE

Address	Name	Data Type	Default	Min	Max	Access Level	Description
9063	BlowerSpeed	Signed 16-bit	0			READ/WRITE	MONITORS THE CURRENT SPEED OF INDOOR MOTOR. (VALUE SHOULD BE DIVIDED BY 10)
9064	OFMSpeed	Signed 16-bit	0			READ/WRITE	SET OPERATING SPEED OF THE INDOOR MOTOR
9065	HeadPressureCtrl	Boolean	0			READ/WRITE	0: OUTDOOR FAN RUNS AT "OFMSpeed" 1:OUTDOOR FAN RUNS MODULATES TO MAINTAIN LIQUID LINE TEMP OF 100 F
9066	OFM_ProportionalVal	Real	0			READ/WRITE	PROPORTIONAL VALUE FOR MODULATING THE OUTDOOR FAN MOTOR.
9068	OFM_IntegralVal	Real	0			READ/WRITE	INTEGRAL VALUE FOR MODULATING THE OUTDOOR FAN MOTOR.
9070	HeadPressureScaled1	Real	0			READ	MONITOR LIQUID LINE TEMPERATURE OF CIR- CUIT 1
9072	HeadPressureOffset1	Real	0			READ/WRITE	ALLOWS USER TO CALIBRATE THE MEASURED LIQUID LINE TEMPERATURE OF CIRCUIT 1
9078	HeadPressureScaled2	Real	0			READ	MONITOR LIQUID LINE TEMPERATURE OF CIR- CUIT 2
9080	HeadPressureOffset2	Real	0			READ/WRITE	ALLOWS USER TO CALIBRATE THE MEASURED LIQUID LINE TEMPERATURE OF CIRCUIT 2
9086	ECON_TempSP	Real	0			READ/WRITE	CHANGEOVER SETPOINT FOR THE ECONOMIZER
9088	ECON_OAT_scaled	Real	0			READ	ALLOWS USER TO CALIBRATE THE MEASURED OUTDOOR AIR TEMPERATURE
9092	CoolOption	Signed 16-bit	0			READ/WRITE	0 : DX COOLING ONLY 1 : ECONOMIZER
9093	OAH_Offset	Real	0			READ/WRITE	ALLOWS USER TO CALIBRATE THE MEASURED OUTDOOR AIR HUMIDITY
9095	MAT_Offset	Real	0			READ/WRITE	ALLOWS USER TO CALIBRATE THE MEASURED SUPPLY AIR TEMPERATURE
9097	EconDamper_HighLimit	Real				READ/WRITE	MAXIMUM ALLOWED POSITION FOR THE DAMPER
9099	EconDamper_LowLimit	Real	0		40	READ/WRITE	MINIMUM ALLOWED POSITION FOR THE DAMPER
9101	EconDamper_Manu- alCtrl	Boolean	0			READ/WRITE	0 : DAMPER MODULATES 1 : DAMPER OPENS TO THE POSITION "EconDamper_ManualVal". DURING ECONOMIZING
9102	EconDamper_ManualVal	Real	0			READ/WRITE	POSITION THE DAMPER OPENS TO DURING ECONOMIZING
9104	EconDamper_ActualPos	Real	0			READ	POSITION THE CONTROLLER IS REQUESTING THE DAMPER TO OPEN UP TO
9106	UnitNum	Signed 16-bit	1	1		READ/WRITE	BACNET ID
9116	Stg1_Speed	Signed 16-bit	50			READ/WRITE	INDOOR MOTOR COOL SPEED - STAGE 1
9117	Stg2_Speed	Signed 16-bit	55			READ/WRITE	INDOOR MOTOR COOL SPEED - STAGE 2
9118	Stg3_Speed	Signed 16-bit	60			READ/WRITE	INDOOR MOTOR COOL SPEED - STAGE 3
9119	Stg4_Speed	Signed 16-bit	60			READ/WRITE	INDOOR MOTOR COOL SPEED - STAGE 4
9120	Stg5_Speed	Signed 16-bit	65			READ/WRITE	INDOOR MOTOR COOL SPEED - STAGE 5
9121	G_Speed	Signed 16-bit	50			READ/WRITE	FAN ONLY SPEED
9122	W2_Speed	Signed 16-bit	65			READ/WRITE	INDOOR MOTOR - HEATER SPEED
9135	DirtyFilter_Warning	Boolean	0			READ	
9176	EconForceClose	Boolean	0			READ/WRITE	ALLOWS USER TO FORCE ECONOMIZER CLOSE. 0: OFF 1: CLOSE DAMPER
9180	SystemCapacityOp	Signed 16-bit	0			READ/WRITE	0:Full Capacity; 1:Staged Capacity ; 2: Dual Compressor Op

Appendix D: PLC BACNET Analog Variables


PARAMETER Name	Description	Units	Access
BAV1_T-StatMode	0:OFF, 1:COOL, 2:HEAT, 3:AUTO	Binary	Read/Write
BAV3_CoolSetpoint	Cooling Setpoint	Temp (F)	Read/Write
BAV4_HeatSetpoint	HeatingSetpoint	Temp (F)	Read/Write
BAV5_HumiditySetpoint	Humidity Setpoint	RH (%)	Read/Write
BAV6_RoomTemp	Average Temperature Used To Control Unit	Temp (F)	ReadOnly
BAV7_RoomHumidity	Average Humidity Used To Control Unit	RH (%)	ReadOnly
BAV10_OutdoorAirTemp	Measured Outdoor Air Temperature	Temp (F)	Read Only
BAV11_OutdoorAirTempOffset	Offset value for calibrating Outdoor Air Temperature measurement	Temp (F)	Read/Write
BAV12_IndoorBlowerSpeed	Monitors the speed at which the indoor motor is being requested to operate at	(%)	Read Only
BAV13_OutdoorBlowerSpeed	Speed setting at which the outdoor motor will operate when requested	(%)	Read/Write
BAV14_CoolOption	0:Mechanical Cooling Only, 1: Economizer OR Mechanical Cooling , 2:Economizer AND Mechanical Cooling	N/A	Read/Write
BAV15_EconomizerTempSP	Temperature below which the economizer initiates on an active cooling request	Temp (F)	Read/Write
BAV16_EcoonmizerHumSP	Humidity at which the economizer initiates on cooling request. Only Applicable is "BAV14_CoolOption" and "BAV58_EconomizerSensorSelection" are not equal to 0	(%)	Read/Write
${\bf BAV17_EconomizerDamperMinimumPos}$	Minimum position of the economizer damper	Open (%)	Read/Write
BAV18_EconomizerDamperMaximumPos	Maximum position of the economizer damper	Open (%)	ReadOnly
BAV19_HeadPressure1	Monitors the Liquid Line Temperature of Circuit 1	Temp (F)	Read Only
BAV20_SuctionPressure1	Monitors the Suction Line Temperature of Circuit 1	Temp (F)	Read Only
BAV21_HeadPressure2	Monitors the Liquid Line Temperature of Circuit 2	Temp (F)	Read Only
BAV22_SuctionPressure2	Monitors the Suction Line Temperature of Circuit 1	Temp (F)	Read Only
BAV23_CoolStg1Speed	Indoor Blower Speed setpoint for Cool Stage 1	(%)	Read/Write
BAV24_CoolStg2Speed	Indoor Blower Speed setpoint for Cool Stage 2 (Stage 1 Cooling in 2 Stage Operation)	(%)	Read/Write
BAV25_CoolStg3Speed	Indoor Blower Speed setpoint for Cool Stage 3	(%)	Read/Write
BAV26_CoolStg4Speed	Indoor Blower Speed setpoint for Cool Stage 4	(%)	Read/Write
BAV27_CoolStg5Speed	Indoor Blower Speed setpoint for Cool Stage 5 (Stage 2 Cooling in 2 Stage Operation)	(%)	Read/Write
BAV28_HeatStg1Speed	Indoor Blower Speed setpoint for Heating operation	(%)	Read/Write
BAV29_BlowerOnlySpeed	Indoor Blower Speed setpoint for fan only operation	(%)	Read/Write
BAV30_EconomizerPosition	Economizer Damper Position	Open (%)	ReadOnly
BAV31_EconomizerManualValue	Economizer manual value. Only applicable when economizer is in manual mode (BBV31=1)	Open (%)	Read/Write
BAV32_CustomerTemp1	(Not Part of Standard Offering) Measure value for Temperature Sensor 1	Temp (F)	ReadOnly
BAV33_CustomerTemp2	(Not Part of Standard Offering) Measure value for Temperature Sensor 2	Temp (F)	ReadOnly
BAV34_CustomerTemp3	(Not Part of Standard Offering) Measure value for Temperature Sensor 3	Temp (F)	ReadOnly
BAV35_CustomerTemp4	(Not Part of Standard Offering) Measure value for Temperature Sensor 4	Temp (F)	ReadOnly

PARAMETER Name	Description	Units	Access
BAV36_CustomerTemp5	(Not Part of Standard Offering) Measure value for Temperature Sensor 5	Temp (F)	ReadOnly
BAV68_CustomerTemp6	(Not Part of Standard Offering) Measure value for Temperature Sensor 6	Temp (F)	ReadOnly
BAV32_CustomerTemp1	Qty of Humidity Sensors Used in Averaging Control	Temp (F)	Read/Write
BAV42_CustomerHum1	(Not Part of Standard Offering) Measure value for Humidity Sensor 1	RH (%)	ReadOnly
BAV43_CustomerHum2	(Not Part of Standard Offering) Measure value for Humidity Sensor 2	RH (%)	ReadOnly
BAV44_CustomerHum3	(Not Part of Standard Offering) Measure value for Humidity Sensor 3	RH (%)	ReadOnly
BAV45_CustomerHum4	(Not Part of Standard Offering) Measure value for Humidity Sensor 4	RH (%)	ReadOnly
BAV46_CustomerHum5	(Not Part of Standard Offering) Measure value for Humidity Sensor 5	RH (%)	ReadOnly
BAV69_CustomerHum6	(Not Part of Standard Offering) Measure value for Humidity Sensor 6	RH (%)	ReadOnly
BAV52_MixedAirSensorValue	Measured Value of the Mixed Air Sensor	Temp (F)	ReadOnly
BAV54_SupplyAirSensorValue	Measured Value of the Supply Air Sensor (Standard Design uses the "BAV54" for both supply and mixed measurement)	Temp (F)	ReadOnly
BAV55_SupplyAirTempOffset	Offset value to calibrate the value measured by the Supply Air Temperature Sensor	Temp (F)	Read/Write
BAV56_MixedAirTempOffset	Offset value to calibrate the value measured by the Mixed Air Temperature Sensor	Temp (F)	Read/Write
BAV57_OutdoorAirHumidityOffset	Offset value to calibrate the value measured by the Outdoor Humidity Sensor	RH (%)	Read/Write
BAV58_EconomizerSensorSelection	0 : Drybulb, 1: Enthalpy + Drybulb , 2: Dewpoint + Drybulb	Binary	Read/Write
BAV59_EconomizerTempDif	Deadband offset value for Economizer Temperature process variable as it relates to the Space Temperature	Temp (F)	Read/Write
BAV60_EconomizerEnthalpyDif	Deadband offset value for Economizer Enthalpy process variable as it relates to the Space Enthalpy	(BTU/lb-air)	Read/Write
BAV61_EconomizerDewpointSetpoint	Economizer Dewpoint Lockout Setpoint	Temp (F)	Read/Write
BAV63_SpaceEnthalpy	Measured Enthalpy of Space	(BTU/lb-air)	Read Only
BAV65_OutdoorEnthalpy	Measured Outdoor Enthalpy	(BTU/lb-air)	Read Only
BAV66_OutdoorDewpoint	Measured Outdoor Dewpoint	Dewpoint (F)	Read Only
BAV67_OutdoorHumidity	Measured Outdoor Humidity	RH (%)	Read Only
BAV74_RevisionLevel	Revision Level of the PLC software	N/A	Read Only

Appendix E: PLC BACNET Binary Variables


PARAMETER Name	Description	Units	Access
BBV0_HPS1_R	Monitor Circuit 1 High Pressure Input. 0:Fault, 1:OK	Binary	ReadOnly
BBV1_LPS1_R	Monitor Circuit 1 Low Pressure Input. 0:Fault, 1:OK	Binary	ReadOnly
BBV2_HPS2_R	Monitor Circuit 2 High Pressure Input. 0:Fault, 1:OK (Only Applicable on Dual Compressor Unit)	Binary	ReadOnly
BBV3_LPS2_R	Monitor Circuit 2 Low Pressure Input. 0:Fault, 1:OK (Only Applicable on Dual Compressor Unit)	Binary	ReadOnly
BBV4_EMS_R	Monitor Emergency Shutdown Input. 0:Fault, 1:OK	Binary	ReadOnly
BBV5_Cooling1_R	Monitor Compressor Circuit 1 Request. 1:ON, 0:OFF	Binary	ReadOnly
BBV6_Cooling2_R	Monitor Compressor Circuit 2 Request. 1:ON, 0:OFF (Only Dual Compressor Unit)	Binary	ReadOnly
BBV7_IndoorFan_R	Monitor Request for the Indoor Blower Motor. 1:ON, 0:OFF (Verifies if there is a call for the blower to be on)	Binary	ReadOnly
BBV10_RemoteShutdown_RW	Allow end user to Remote Shutdown the HVAC Unit. 1:Active, 0:Inactive (Emergency Shutdown)	Binary	Read/Write
BBV11_CoolReqStg1_RW	Variable for Requesting first stage cooling (Y signal). 1:Request, 0: No Request	Binary	Read/Write
BBV12_CoolReqStg2_RW	Variable for Requesting second stage cooling (Y2 signal). 1:Request, 0: No Request	Binary	Read/Write
BBV13_HeatReqStg1_RW	Variable for Requesting first stage heating (W1 signal). 1:Request, 0: No Request	Binary	Read/Write
BBV15_IndoorFanReq_RW	Variable for Requesting Fan Only. 1:Request, 0: No Request	Binary	Read/Write
BBV17_BlowerSetting_RW	Indoor Blower Control Setup. 0:Auto , 1:ON Mode. In auto Mode, the fan cycles when running. In "On" mode the fan runs continuously.	Binary	Read/Write
BBV20_EconomizerDamperControl_RW	Variable for controlling the Economizer Damper Manually or have it automatically controlled. In Manual Mode, opening position is set by end user (BAV31_EconomizerManualValue). 0:Automatic Mode, 1: Manual Mode. Note that the dampers will only open when there is a request for economizer.	Binary	Read/Write
BBV22_DirtyFilter_R	Variable for monitoring the status of the Dirty Filter switch. 1:OK, 0:Dirty	Binary	ReadOnly
BBV23_EconDamperForceClose	Variable for forcing damper close. 1: Close OA Damper, 0: Normal Operation (Emergency OA Shutdown)	Binary	Read/Write
BBV24_EconDamperForceOpen	Variable for forcing damper into manual control. This will force damper to position set by end user at variable "BAV31_ EconomizerManualValue". Note that this is does not depend on an active request for economizer.	Binary	Read/Write
BBV25_HumidityCtrlEnable	Dehumidification Functionality Enable/Disable. 1:ENABLE, 0:DISABLE	Binary	Read/Write

Appendix F: Fresh Air Damper Installation




Fresh Air Hood Adjustment (non-economozer air conditioners only)

The fresh air hood is located on the inside, behind the slots on the bottom front panel. To access the hood, remove the screws that hold the front panel. The air flow can be adjusted from no (0%) fresh air to approximately 15% of rated air flow of fresh air, in 5% increments. The hood is shipped from the factory in the closed position (no fresh air). To provide fresh air, remove the two screws on either side of the hood and reposition as desired.



Fresh Air Hood Damper

Appendix G: CFH3240A Center Supply/Top Return w/ Economizer Exhaust Hood Installation



- A. MAKE SURE FACTORY SUPPLIED GASKET IS PROPERLY ATTACHED TO THE BOTTOM FLANGES OF THE HOOD ASSY (ITEM 1)
- B. PLACE HOOD ASSY (ITEM 1) ON TOP OF UNIT WITH SLOTTED VENTS TOWARDS THE FRONT OF THE UNIT
- C. ALIGN HOLES IN THE HOOD ASSY FLANGES WITH PREDRILLED HOLES IN THE TOP PANEL OF UNIT (ITEM 2)
- D. SCREW INTO PLACE WITH SHEET METAL SCREWS PROVIDED
- E. ADD SILICONE BEAD AROUND THE TWO SIDES AND REAR OF THE HOOD ASSY


Appendix H: Optional Condenser Filter Installation

STEP 1-REMOVE COIL GUARD SAVE SCREWS FOR MOUNTING FILTER ASSY STEP 2-SCREW FRAME SIDES AND BOTTOM IN COIL GUARD MOUNTING HOLES

STEP 3-SLIDE FILTER INTO FRAME

STEP 4- SCREW FRAME TOP INTO COIL GUARD MOUNTING HOLES

STEP 5-REPEAT 1-4 FOR OTHER SIDE PANEL



S/12908**		EXTERNAL CONDENSER FILTER ASSY 300-360		_
	SML17015	EXTERNAL COND COIL SIDE MGA 300-360	4	_
	SML17016	EXTERNAL COND COIL BOT MGA 300-360	2	_
	SML17017	EXTERNAL COND COIL TOP MGA 300-360	2	
	93288	FILTER CONDENSER 300-360 64.75X36.625	4	_
				_
S/12907**		EXTERNAL CONDENSER FILTER ASSY 180-240	_	_
	SML17013	EXTERNAL COND COIL SIDE MGA 180-240	4	_
	SML17014	EXTERNAL COND COIL BOT MGA 180-240	2	_
	SML17018	EXTERNAL COND COIL TOP MGA 180-240	2	
	93287	FILTER CONDENSER 180-240 44.875X36.5	4	
				_
S/12906**		EXTERNAL CONDENSER FILTER ASSY 120-+150		
	SML17009X	EXTERNAL COND COIL SIDE 1 MGA 90-150	2	_
	SML17010	EXTERNAL COND COIL SIDE 2 MGA 90-150	2	
	SML17012	EXTERNAL COND COIL BOT MGA 120-150	2	
	SML17019	EXTERNAL COND COIL TOP MGA 120-150	2	
	93286	FILTER CONDENSER 120-150 36.875X28	2	
040005++		EXTERNAL CONDENSED SILTED ACCUSO	-	_
S/12905**		EXTERNAL CONDENSER FILTER ASSY 90	-	_
		EXTERNAL COND COIL SIDE 1 MGA 90-150	2	_
	SML17010	EXTERNAL COND COIL SIDE 2 MGA 90-150	2	_
	SML17011	EXTERNAL COND COIL BOT MGA 90	2	_
	SML17020	EXTERNAL COND COIL TOP MGA 90	2	
	93285	FILTER CONDENSER 120-150 30.875X28	2	

Appendix I: DPC200 Differential Pressure Controller



Installation and operation manual

DPC200 - DIFFERENTIAL PRESSURE CONTROLLER

Low pressure with PI-control-mode





Manufacturer: Arthur Grillo GmbH

Am Sandbach 7 40878 Ratingen

Phone: +49 21 02 - 47 10 22 **Fax:** +49 21 02 - 47 58 82

E-Mail: info@grillo-messgeraete.de **Website:** www.grillo-messgeraete.de

www.sensor-store.de

Issue: 12/2015

Doc.-no.: DPC200_001_EBM_UK

This documentation including all parts is protected by copyright. Any utilisation or modification other than permissible under the strict limitations of copyright law is prohibited and liable to prosecution without the approval of the Arthur Grillo GmbH. This applies in particular to duplications, translations, microfilming and storage and processing in electronic systems.

3



Table of content

I	Gene	eral safety instructions		04
	1.1	Signal words for safety instructions		04
	1.2	Used pictograms and symbols		04
	1.3	General notes		04
2	Prod	uct description		05
	2.1	Type plate		05
	2.2	Intended use		05
	2.3	Functional description		05
3	Insta	llation		06
	3.1	Dimensions		06
	3.2	Wall mounting		06
4	Start	t up		07
	4 . I	Overview DPC200		07
	4.2	Schematic view inside		07
	4.3	Pressure connections		07
	4.4	Electrical connection		80
	4.5	Zero adjustment		80
5	Оре	ration		08
	5.1	Start menu		80
	5.2	Menu structure		09
	5.3	Measuring mode		10
	5.4	Control mode		11
	5.5	Adjustable parameters		12
	5.6	Function alarm output		13
6	Main	tenance		13
7	Warı	ranty		14
8	Trou	bleshooting		14
9	Disp	osal		14
10	Spec	ifications		15
	10.1	CE-labelling		16
П	Orde	ering information		16
		Docno.: DPC200_01_EBM_UK	Issue: 12/2015	



I. General safety instructions

I.I Signal words for safety instructions

The safety instructions in this operation manual are designed to prevent hazards. They can be found in the operation manual before an operation / task / activity is described, which can entail a possible hazard.



Identification of a hazard with a low risk, which can lead to material damage or minor or moderate bodily injuries.



Signal word for important information regarding the product, which needs to be specifically pointed out.





Type of hazard

Hazard source Hazard prevention

1.2 Used pictograms and symbols

In this manual the following symbols are used:



General hazard symbol (danger, warning, caution)



General information

1.3 General notes





This manual contains information for installation and operation of the pressure controller and is exclusively for the operator and expert staff. The guidelines in this manual will help to avoid danger and downtime.

2

Doc.-no.: DPC200_01_EBM_UK

Issue: 12/2015



2. Product description

The differential pressure controller DPC200 measures low pressure of inert gases, particularly of air.

2.1 Type plate

١.	Product name	pressure controller	DPC200-EP500
2.	Measuring range	measurement range: 500 Pa 2.	
	Supply voltage	supply voltage: 3. $U_S (1+2-) = 10 30 \ V$	
	Signal output	signal output: 4. U _{out} (3+ 4-) = 0 10 \	CE CE
5.	Serial no.	part-no.: 2572 5 serial-no.: 15. 4	700 (€
6.	Manufacturer		Made in Germany

2.2 Intended use

This device is primarily intended for use with air conditioning systems, room pressure control or filter control with ebm-papst continuously variable speed fans. It can be operated solely as a sensor (measuring mode) or closed loop controller for pressure / volumetric flow rate control. As analogue output the operator can use a signal from 0 ...10 V DC. Depending on the settings the signal has different meanings:

- If the device is used as a pressure sensor, the output signal is proportional to the measured pressure.
- 2. As a volume flow sensor the device outputs a square root signal.
- 3. With closed loop pressure or volume flow the output signal stands for the control variable of the Pl-control.

2.3 Functional description

A soft silicone diaphragm is used as sensor. Under the influence of the differential pressure the diaphragm displaces a measuring spring until the spring force compensates for the pressure pushing on the diaphragm. A contactless differential transformer and suitable electronics convert this displacement into a continuously variable output voltage signal. The DPC200 provides two function options:

- 1. On the one hand it is used as a measuring device. In the measuring mode the differential pressure is shown on the display, and a proportional 0... 10V DC output signal is provided.
- 2. Besides the measuring mode the DPC200 also can be operated in a control mode. Two setpoints can be adjusted in the device and can be selected with the potential free contact input. The PI-Algorithm matches the measured differential pressure with the setpoint and operates the control variable so that a constant pressure results. The control variable is given as a 0...10 V DC output signal.

Instead of the quantity 'differential pressure' also the quantity 'volume flow' can be used for measuring and for control.

Doc.-no.: DPC200 01 EBM UK Issue: 12/2015



3. Installation

The differential pressure controller DPC200 is designed for wall mounting.

- The mounting surface must be solid enough and vibration-free.
- The environment has to fulfil the ambient climatic conditions as given in the technical data.

CAUTION

Material damage



Read the manual carefully before installation and operation Only experienced staff may connect the device and bring it into operation.






- The device is position depended.
- The DPC200 must be mounted vertically.

3.1 Dimensions

All dimensions in mm.



3.2 Wall mounting

- I. Hold the DPC200 against the wall. Mark the mounting holes.
- 2. Drill mounting holes for properly sized screws.
- 3. Put the screws through the housing mounting holes.
- 4. Tighten screws.

6

Doc.-no.: DPC200_01_EBM_UK

Issue: 12/2015


7




4. Start up

4.1 Overview DPC200

- I. Front cover
- 2. Cable gland
- 3. Pressure connection I
- 4. Pressure connection 2
- 5. Cable gland



4.2 Schematic view inside




Button T1 and T2 serve for the operation of the menu

4.3 Pressure connections

Connect all pressure connections properly with plastic tubing (inner diameter 5 or 6mm).




4.4 Electrical connection



- I. Unscrew screws of the front cover.
- 2. Open front cover.
- 3. Use M16 cable glands for connecting wiring to terminals.

4.5 Zero adjustment

The output signal offset can be zeroed from the outside with a small bar magnet. Do not use buttons T1 or T2.



Adjustment:

- Remove the tubing from the pressure connections.
- Hold the bar magnet (N/S) as shown here to the zero point adjustment for a short period of time to activate an internal reed switch

The new zero point will be displayed and stored.


5. Operation

5.1 Start menu

For operating the menu, unscrew the front cover to reach buttons T1 and T2.



5.2 Menu structure





5.3 Measuring mode

Display	Action
ΔP Measurement 200 Pa Start menu: Press button T1 approx. two seconds	
menu	Press button T2 to get to the next menu item
unit metric	Press button T1 to switch between: metric <=> imperial Press button T2 to get to the next menu item
operating mode control mode	Press button T1 to switch between: measuring mode <=> control mode Press button T2 to get to the next menu item
parameter diff. pressure	Press button T1 to switch between: diff. pressure <=> volume flow Press button T2 to get to the next menu item

	If selected parameter = diff. pressure
	Button TI: reset value
limit switch	Button T2: set value
150 Pa	Button T1: confirm value, display flashes once
	Press button T2 to get to the next menu item
hadrand saufins	Press button TI to leave the menu
back and confirm	Press button T2 to stay in the menu

	If selected parameter = volume flow than follows the additional input for the k-factor
fan k-factor k = 70	Button T1: reset value Button T2: set value Button T1: confirm value, display flashes once Press button T2 to get to the next menu item
limit switch 300 m³/h	Button T1: reset value Button T2: set value Button T1: confirm value, display flashes once Press button T2 to get to the next menu item
back and confirm	Press button T1 to leave the menu Press button T2 to stay in the menu

10



5.4 Control mode

Display	Action
Δ P Measurement 200 Pa	Start menu: Press button TI approx. two seconds
menu	Press button T2 to get to the next menu item
unit metric	Press button T1 to switch between: metric <=> imperial Press button T2 to get to the next menu item
operating mode control mode	Press button T1 to switch between: measuring mode <=> control mode Press button T2 to get to the next menu item
parameter diff. pressure	Press button T1 to switch between: diff. pressure <=> volume flow Press button T2 to get to the next menu item

	If selected parameter = diff. pressure resp. after the input of the k-factor follows:
setpoint I 50 Pa	Button T1: reset value Button T2: set value Button T1: confirm value, display flashes once Press button T2 to get to the next menu item
setpoint 2 250 Pa	Button T1: reset value Button T2: set value Button T1: confirm value, display flashes once Press button T2 to get to the next menu item
output voltage U = 10,0 V DC	Button T1: reset value Button T2: set value Button T1: confirm value, display flashes once Press button T2 to get to the next menu item
P - parameter 50	Button T1: reset value Button T2: set value Button T1: confirm value, display flashes once Press button T2 to get to the next menu item
l - parameter 3,15	Button T1: reset value Button T2: set value Button T1: confirm value, display flashes once Press button T2 to get to the next menu item
controlling mode positive / heating	Press button T1 to switch between: positive / heating <=> negative / cooling Press button T2 to go to the next menu
back and confirm	Press button T1 to leave the menu Press button T2 to stay in the menu

12



	If selected parameter = volume flow than follows the additional input for the k-factor
fan k-factor	Button T1: reset value Button T2: set value
k = 70	Button T1: confirm value, display flashes once Press button T2 to get to the next menu item

5.5 Adjustable parameters

Parameter	Selection or parameter range	Default setting
Unit	Metric or imperial	metric
Operating mode:	Measuring mode or control mode	measuring mode
Parameter	Differential pressure ΔP [Pa or InH2O] Volume flow V [m³/h or cfm]	differential pressure ΔP [Pa]
K-factor:	Volume flow calculation according to: V = k · √∆p with: V = Volume flow in m³/h or cfm k = flow factor, adjustment range: I1000 measuring range up to 4000 Pa ∆p = differential pressure in Pa or InH20 Volume flow calculation up to 65,500 m³/h (38,514 cfm) In measuring or control mode Maximum volume flow (V _{max}) Measuring range: 50 Pa, k=1000 → V _{max} = 7,071 m³/h; (4,157 cfm) Measuring range: 500 Pa, k=1000 → V _{max} = 22,360 m³/h; (13,147 cfm) Measuring range: 1000 Pa, k=1000 → V _{max} = 31,622 m³/h; (18,593 cfm) Measuring range: 2000 Pa, k=1000 → V _{max} = 44,721 m³/h; (26,295 cfm) Measuring range: 4000 Pa, k=1000 → V _{max} = 63,245 m³/h; (37,188 cfm)	K = 70
Limit values:	Differential pressure from 0 % up to 100 % of measuring range. Volume flow from 5 % up to 100 % of measuring range, k-factor is considered.	OFF
Nominal values (setpoints):	Differential pressure from 0 % up to 100 % of measuring range. Volume flow from 5 % up to 100 % of measuring range, k-factor is considered.	Set 1:75 % Set 2:25 %
Output voltage:	010V DC	U _{out} = 10V DC
P-gain:	01000	P = 50
I-gain:	0100	I = 3.15
Control characteristic:	positive/(heating): Control deviation = set value — actual value The output increases when set value > actual value. negative/(cooling): Control deviation = actual value — set value The output increases when actual value > set value	positive / heating



5.6 Function alarm output

The DPC200 has an open collector alarm output; depending on the operating mode the function is different.

At the **alarm event** a contact between terminal no. 7 and no. 8 gets low-resistive and can be loaded with a maximum of $30\,V$ DC/ $30\,mA$. When the alarm is switched off the contact will be high-resistive.

During alarm state in the control mode / measuring mode an exclamation point is displayed (2nd line / 16th character).

Control mode:

In order to recognize the limits of control, the alarm output in the control mode refers to the set maximum output voltage ($MaxU_{out}$). $MaxU_{out}$ can be set in the menu item "output voltage".

In the default setting the value is set to 10 V DC.

Alarm ON: Output voltage for 12 seconds constantly greater than: $0.95 \cdot \text{MaxU}_{\text{out}}$ Alarm OFF: Output voltage for 12 seconds constantly less than: $0.9 \cdot \text{MaxU}_{\text{out}}$

Measuring mode:

For limit value monitoring a limit value can be entered. This value is set in the menu item "limit switch". The previously set parameters are taken into account (unit, parameter, k-factor and the measuring range).

In the default setting the limits are not active. Display 2nd line: "OFF" Alarm ON: Measurement for 12 seconds constantly greater than 1.0 • limit value Alarm OFF: Measurement for 12 seconds constantly less than 0.95 • limit value



6. Maintenance

The DPC200 contains no wearing or consumable parts. Servicing is not required. On request, Arthur Grillo GmbH offers an annual calibration with factory certificate. For information, please contact:



Arthur Grillo GmbH Phone: +49 21 02 - 47 10 22
Am Sandbach 7 Fax: +49 21 02 - 47 58 82
40878 Ratingen E-Mail: info@grillo-messgeraete.de

7. Warranty

Warranty and liability claims for personal and property damage are excluded if they are caused by one or more of the following reasons:

- Improper use of the device.
- Improper installation, commissioning, operation and maintenance of the device.
- Unauthorized modifications to the device beyond the intended use.
- Disasters due to external influences and force majeure.

8. Troubleshooting

Description	Activity
Display does not show anything	Check electrical connection
Measurement stays zero	Function test with a slight pressure increase in measuring mode for differential pressure
Measuring error	Perform zeroing as described in chapter 4.5.
Error remains	Contact manufacturer

9. Disposal

Dispose of parts so as not to endanger human health or the environment. Follow the laws in the country of use for disposing of electronic components and devices during disposal.



10. Specifications

Measuring medium: Air or inert gases

Measuring principle: Silicon diaphragm with spring and differential transformer

Lowest span: 0...50 Pa
Highest span: 0...4000 Pa
Overpressure protection: 0.2 bar
Static pressure: max. 0.2 bar

Pressure connections: tubing 5 mm ø or 6 mm ø

Enclosure: UL 94 HB; Case polyamid, cover ABS Electrical connections: cable inlet M16x1.5, screw terminal

Electronic protection against reversed polarization

Supply voltage: 10...30 Vdc; 24 Vac (±15%)

Current consumption: approx. 10 mA @ 10 Vdc, ca. 12 mA @ 24 Vdc

Output: 0...10 V $(I_{max} = 0.5 \text{ mA} @ 10 \text{ Vdc}, I_{max} = 2 \text{ mA} @ 20 \text{ Vdc})$

Alarm output: Open Collector, max. 30 V / 30 mA

Display: LCD-Display, 2 x16 characters
Mode: Measuring mode or controlling mode

Controlling algorithm: PI

Setpoints: 2 setpoints adjustable within software,

Setpoints are selectable with floating contact input

Protection class: IP 54 according EN 60529

Ambient temperature: -10...50 °C Storage temperature: -25...60 °C Weight: approx. 250 g

Mounting: vertical, position dependence by turning of 90°: approx. 25 Pa

Interference / emission: according EN 61000-6-2, EN 61000-6-3, CE mark

Influences / limits: Zero error: $\pm 0.75 \%$

Sum of linearity and hysteresis

 $\begin{array}{ll} \mbox{(depends on measuring range):} & \pm 0.5 \ \% \ ... \pm 1 \ \% \\ \mbox{Temperature drift, zero point:} & \pm 0.3 \ \% \ / \ 10 \ K \\ \mbox{Temperature drift, span:} & \pm 0.2 \ \% \ / \ 10 \ K \end{array}$

15

Doc.-no.: DPC200_01_EBM_UK Issue: 12/2015



10.1 CE-labelling

As an electric device the DPC200 falls within the scope of the directive 2004/108/EG (EMV-directive). In the scope of the EMV-directive the following norms were applied:

DIN EN 61000-6-2:2006-03 Berichtigung 1:2011-06	Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments
	Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light industrial environments

You can order the Declaration of Conformity at:

Arthur Grillo GmbH

Am Sandbach 7 40878 Ratingen Phone: +49 21 02 - 47 10 22

Fax: +49 21 02 - 47 58 82 E-Mail: info@grillo-messgeraete.de

11. Ordering information

16

Article	ltem no.
Differential pressure controller DPC200 Measurement range: 050 Pa	2570
Differential pressure controller DPC200 Measurement range: 0500 Pa	2572
Differential pressure controller DPC200 Measurement range: 01000 Pa	2574
Differential pressure controller DPC200 Measurement range: 02000 Pa	2576
Differential pressure controller DPC200 Measurement range: 04000 Pa	2578
Mounting set M-DS with screws, bleeders and 2m plastic tube (4 x 1,5 mm)	25110

Notes: